

Operating Instructions Pellet boiler PECO 15-35



Translation of the original German operating instructions for the operator

Read and follow the instructions and safety information!

Technical changes, typographical errors and omissions reserved!

B1610020_en | Edition 17/06/2020



Table of contents

1	General	5
1.1	Product overview	6
2	Safety	7
2.1	Hazard levels of warnings	7
2.2	Pictograms used	8
2.3	General safety information	9
2.4	Permitted uses	10
2.4.1	The Clean Air Act 1993 and Smoke Control Areas	10
2.4.2	Permitted fuels	11
	<i>Wood pellets</i>	11
2.4.3	Non-permitted fuels	12
2.5	Qualification of operating staff	12
2.6	Protective equipment for operating staff	12
2.7	Safety Devices	13
2.8	Residual risks	14
2.9	Emergency procedure	15
2.9.1	Overheating of the system	15
2.9.2	Smell of flue gas	15
2.9.3	Fire in the system	15
3	Notes for operating a heating system	16
3.1	Installation and approval of the heating system	16
3.2	General information for installation room (boiler room)	16
3.3	Room air-independent operation	17
3.4	Requirements for central heating water	18
3.5	Notes for using pressure maintenance systems	20
3.6	Use with storage tank	21
3.7	Chimney connection/chimney system	21
4	Operating the system	22
4.1	Assembly and initial startup	22
4.2	Switching on the power supply	23
4.3	Operating the WOS lever	23
4.4	Operate the boiler using the touch display	24
4.4.1	Overview of the touch display	24
	<i>Status display</i>	25
	<i>Control icons</i>	25
	<i>Display icons for froeling-connect/remote control</i>	26
	<i>Navigation within the system menu</i>	26
	<i>Changing parameters</i>	28
	<i>Change time window</i>	28
	<i>Quick menu</i>	29
4.4.2	Select information displays	30

4.4.3	Switch boiler ON/OFF	32
4.4.4	Change boiler mode	33
4.4.5	Change date and time	34
4.4.6	Change desired DHW tank temperature	34
4.4.7	One-time extra loading of an individual DHW tank	35
4.4.8	One-time extra loading of all existing DHW tanks.	35
4.4.9	Set the heating curve of a heating circuit	36
4.4.10	Change room temperature (heating circuit without room temperature sensor)	37
4.4.11	Change room temperature (heating circuit mit room temperature sensor)	37
4.4.12	Switch heating circuit mode	38
4.4.13	Lock display/switch user level	39
4.4.14	Change the name of the components	39
4.4.15	Configure the holiday program	40
4.5	Switch the boiler ON/OFF on the room console	41
4.6	Adjust the pellet consumption counter after filling the store room	42
4.6.1	Adjust the pellet consumption counter to the fuel	42
4.6.2	Setting the automatic notification for minimum level	44
4.6.3	Resetting the pellet consumption counter	45
4.7	Checking the fill level of the ash container and emptying if required	45
4.7.1	Check the fill level of the ash container	46
4.7.2	Empty ash container	47
4.8	Switching off the power supply	47
5	Servicing the system	48
5.1	General information on servicing	48
5.2	Required tools	49
5.3	Maintenance work by the operator	50
5.3.1	Inspection	50
	<i>Checking the system pressure</i>	50
	<i>Checking the safety valve</i>	50
	<i>Checking the quick vent valve</i>	50
5.3.2	Cleaning	51
	<i>Cleaning the burn-out tray, burner insert and combustion chamber</i>	51
5.3.3	Periodic inspection and cleaning	52
	<i>Clean the induced draft fan</i>	52
	<i>Clean the heat exchanger and WOS springs</i>	53
	<i>Cleaning the flue gas pipe</i>	54
	<i>Checking the draught controller flap</i>	54
5.4	Maintenance work by technicians	55
5.4.1	Checking and cleaning the combustion grate	56
5.4.2	Cleaning the measurement line of the underpressure controller	57
5.4.3	Cleaning the Lambda probe	58
5.5	Emissions measurement by chimney sweep or regulatory body	59
5.5.1	Switch on the system	59
5.5.2	Start emissions measurement	60
5.6	Replacement parts	60
5.7	Disposal information	60
5.7.1	Disposal of the ash	60
5.7.2	Disposal of system components	60
6	Troubleshooting	61
6.1	General fault with power supply	61

6.1.1	Behaviour of system after a power failure	61
6.2	Excessive temperature	61
6.3	Faults with fault message	62
6.3.1	Procedure for fault messages	62
7	Appendix	64
7.1	Addresses	64
7.1.1	Address of manufacturer	64
	<i>Customer service</i>	64
7.1.2	Address of the installer	64

1 General

Thank you for choosing a quality product from Froling. The product features a state-of-the-art design and conforms to all currently applicable standards and testing guidelines.

Please read and observe the documentation provided and always keep it close to the system for reference. Observing the requirements and safety information in the documentation makes a significant contribution to safe, appropriate, environmentally friendly and economical operation of the system.

The constant further development of our products means that there may be minor differences from the pictures and content. If you discover any errors, please let us know: doku@froeling.com.


Subject to technical change.

Warranty and Guarantee Conditions

Our sale and delivery conditions will be applicable. These conditions have been made available to customers, and customers have been made aware of them at the time of order completion.

You can also find the guarantee conditions on the enclosed guarantee certificate.

1.1 Product overview



- | | |
|-----|--|
| 1 | Pellet boiler PECO |
| 2 | Lambdatronic P 3200 boiler controller, ⇒ See "Overview of the touch display" [page 24] |
| 3 | Main switch |
| 4 | High-limit thermostat (STL) |
| 5 | Door switch |
| 6 | Maintenance opening for combustion chamber (underneath the cover) |
| 6.1 | Inspection glass for checking combustion |
| 7.1 | Ash container for automatic ash removal |
| 8 | Quick start guide |

2 Safety

2.1 Hazard levels of warnings

This documentation uses warnings with the following hazard levels to indicate direct hazards and important safety instructions:



DANGER

The dangerous situation is imminent and if measures are not observed it will lead to serious injury or death. You must follow the instructions!



WARNING

The dangerous situation may occur and if measures are not observed it will lead to serious injury or death. Work with extreme care.



CAUTION

The dangerous situation may occur and if measures are not observed it will lead to minor injuries.

NOTICE

The dangerous situation may occur and if measures are not observed it will lead to damage to property or pollution.

2.2 Pictograms used

The following symbols are used in the documentation and/or on the boiler to show what is required and forbidden and to give warnings.

In accordance with the Machinery Directive, signs fitted directly within the danger area of the boiler indicate immediate hazards or safety procedures. These stickers must not be removed or covered.

	Refer to the operating instructions		Wear safety shoes
	Wear protective gloves		Turn off the main switch
	Keep the doors closed		Wear a dust mask
	Work under the supervision of a second person		Lock
	Unauthorised access prohibited		No fire, open flames or smoking
	Warning - hot surface		Warning - hazardous electrical voltage
	Warning - hazardous or irritant materials		Warning - automatic boiler startup
	Warning of injury to fingers or hands, automatic fan		Warning of injury to fingers or hands, automatic screw
	Warning of injury to fingers or hands, gear/chain drive		Warning of injury to fingers or hands, cutting edge
	Hand injury warning		Warning of injury from being pulled into rotating shafts
	Increased CO concentration warning		Slipping hazard warning

2.3 General safety information



DANGER

If the device is used incorrectly:

Incorrect use of the system can cause severe injury and damage.

When operating the system:

- ☐ Observe the instructions and information in the manuals
- ☐ Observe the details on procedures for operation, maintenance and cleaning, as well as troubleshooting in the respective manuals.
- ☐ Any work above and beyond this (e.g. servicing) must be carried out by a heating engineer approved by Fröling Heizkessel- und Behälterbau GesmbH or by Fröling customer services



WARNING

External influences:

Negative external influences, such as insufficient combustion air or non-standard fuel, can cause serious faults in combustion (e.g. spontaneous combustion of carbonisation gases or flash fires) which can in turn cause serious accidents!

When operating the boiler, please note the following:

- ☐ Instructions and information regarding versions and minimum values, as well as standards and guidelines for heating components in the instructions must be observed.



WARNING

Severe injuries and damage can be caused by an inadequate flue gas system.

Problems with the flue gas system, such as poor cleaning of the flue pipe or insufficient chimney draught, can cause serious faults in combustion (such as spontaneous combustion of carbonisation gases or flash fires).

Take the following precautions:

- ☐ Optimum boiler performance can only be guaranteed if the flue gas system is functioning correctly.

2.4 Permitted uses

The Froling Pellet boiler PECO is designed solely for heating domestic water. Only the fuels specified in the "Permitted fuels" section may be used.

⇒ See "Permitted fuels" [page 11]

The unit should only be operated when it is in full working order. It must be operated in accordance with the instructions, observing safety precautions, and you should ensure you are aware of the potential hazards. The inspection and cleaning intervals in the operating instructions must be observed. Ensure that any faults which might impair safety are rectified immediately.

The manufacturer or supplier is not liable for any damage resulting from non-permitted uses.

Only original spare parts or specific alternative spare parts authorised by the manufacturer may be used. Any kind of change or modification made to the product will invalidate the manufacturer's conformity with the applicable guideline(s). In such cases, the product will need to undergo new hazard evaluation procedures by the operator. The operator will then be fully responsible for the declaration of conformity according to the valid guideline(s) for the product and will need to issue a corresponding declaration for the device. This person will then assume all of the rights and responsibilities of a manufacturer.

2.4.1 The Clean Air Act 1993 and Smoke Control Areas

Under the Clean Air Act local authorities may declare the whole or part of the district of the authority to be a smoke control area. It is an offence to emit smoke from a chimney of a building, from a furnace or from any fixed boiler if located in a designated smoke control area. It is also an offence to acquire an „unauthorised fuel“ for use within a smoke control area unless it is used in an „exempt“ appliance („exempted“ from the controls which generally apply in the smoke control area). The Secretary of State for Environment, Food and Rural Affairs has powers under the Act to authorise smokeless fuels or exempt appliances for use in smoke control areas in England. In Scotland and Wales this power rests with Ministers in the devolved administrations for those countries. Separate legislation, the Clean Air (Northern Ireland) Order 1981, applies in Northern Ireland. Therefore it is a requirement that fuels burnt or obtained for use in smoke control areas have been „authorised“ in Regulations and that appliances used to burn solid fuel in those areas (other than „authorised“ fuels) have been exempted by an Order made and signed by the Secretary of State or Minister in the devolved administrations.

Further information on the requirements of the Clean Air Act can be found here: <http://smokecontrol.defra.gov.uk>

Your local authority is responsible for implementing the Clean Air Act 1993 including designation and supervision of smoke control areas and you can contact them for details of Clean Air Act requirements.

The Froling PE1 Pellet 7, PE1 Pellet 10, PE1 Pellet 15, PE1 Pellet 20, PE1 Pellet 25, PE1 Pellet 30 and PE1 Pellet 35 have been recommended as suitable for use in smoke control areas when burning fuels as listed under "Permitted fuels".

2.4.2 Permitted fuels

Wood pellets

Wood pellets made from natural wood with a diameter of 6 mm

Note on standards

EU:	Fuel acc. to EN ISO 17225 - Part 2: Wood pellets class A1 / D06
and/or:	EN <i>plus</i> / DIN <i>plus</i> certification scheme

General note:

Before refilling the store, check for pellet dust and clean if necessary.

TIP: Fit the Froling PST pellet deduster for separating the dust particles contained in the return air

2.4.3 Non-permitted fuels

The use of fuels not defined in the "Permitted fuels" section, and particularly the burning of refuse, is not permitted.

CAUTION

In case of use of non-permitted fuels:

Burning non-permitted fuels increases the cleaning requirements and leads to a build-up of aggressive sedimentation and condensation, which can damage the boiler and also invalidates the guarantee. Using non-standard fuels can also lead to serious problems with combustion.

For this reason, when operating the boiler:

- ☐ Only use permitted fuels

2.5 Qualification of operating staff

CAUTION



If unauthorised persons enter the Installation room:

Risk of personal injury and damage to property

- ☐ The operator is responsible for keeping unauthorised persons, in particular children, away from the system.

Only trained operators are permitted to operate the unit. The operator must also have read and understood the instructions in the documentation.

2.6 Protective equipment for operating staff

You must ensure that staff have the protective equipment specified by accident prevention regulations!



- For operation, inspection and cleaning:
 - suitable work wear
 - protective gloves
 - sturdy shoes
 - dust mask

2.7 Safety Devices



2.1 BOILER OFF *(switches off the boiler to prevent overheating)*

- ☐ Tap "Boiler OFF"
 - Automatic mode is switched off
 - Control system follows the boiler shutdown procedure
 - Pumps continue to run

3 MAIN SWITCH *(switches off the power supply)*

Before carrying out work on/in the boiler:

- ☐ Tap "Boiler OFF"
 - Automatic mode is switched off
 - Control system follows the boiler shutdown procedure
- ☐ Switch off the main switch and let the boiler cool down

4 SAFETY TEMPERATURE LIMITER (STL) *(protection against overheating)*

The STL (high-limit thermostat) switches off the combustion system when the boiler reaches 100°C. The pumps continue to run. Once the temperature falls below approx. 75°C, the STL can be reset mechanically.

5 DOOR SWITCH *(protection against access to moving components)*

If the insulated door opens while the boiler is operating, all of the units stop to prevent injuries at moving components. If the insulated door remains open for more than 10 seconds, the boiler is switched off automatically.

SV SAFETY VALVE *(protection against overheating/excess pressure)*

When the boiler pressure reaches a maximum of 3 bar, the safety valve opens and the heated water is blown off in the form of steam.

2.8 Residual risks

**! WARNING**

When touching hot surfaces:

Severe burns are possible on hot surfaces and the flue gas pipe!

When work is carried out on the boiler:

- ☐ Shut down the boiler according to procedure ("Boiler off" operating status) and allow it to cool down
- ☐ Protective gloves must usually be worn for work on the boiler, and it should only be operated using the handles provided
- ☐ Insulate the flue gas pipes and do not touch them during operation

**! WARNING**

When inspecting and cleaning the boiler with the main switch on:

Serious injuries possible due to automatic boiler startup!

Before inspection and cleaning work in/on the boiler:

- ☐ Switch the boiler off by tapping "Boiler off"
The boiler follows the shutdown procedure and switches to "Boiler off" mode
- ☐ Allow the boiler to cool for at least 1 hour
- ☐ Switch off the main switch and take precautions to prevent accidental switching on

! WARNING

If non-permitted fuel types are used:

Non-standard fuels can cause serious faults in combustion (e.g. spontaneous combustion of carbonisation gases / flash fires) which can lead to serious accidents!

Take the following precautions:

- ☐ Only use fuels specified in the "Permitted fuels" section of these operating instructions.

2.9 Emergency procedure

2.9.1 Overheating of the system

If the system overheats and the safety devices fail to operate, proceed as follows:

NOTICE! Do not under any circumstances switch off the main switch or disconnect the power supply!

- ☐ Keep all the doors on the boiler closed
- ☐ Open all mixing valve taps, switch on all pumps.
 - ➔ The Froling heating circuit control takes on this function in automatic operation.
- ☐ Leave the boiler room and close the door
- ☐ Open any thermostatic valves on the radiator and ensure sufficient heat dissipation from the rooms

If the temperature does not drop:

- ☐ Contact the installer or Froling customer services
 - ⇒ See "Addresses" [page 64]

2.9.2 Smell of flue gas



DANGER

If you smell flue gas in the boiler room:

Inhaling toxic flue gas can be fatal!

If you smell flue gas in the room where the boiler is installed:

- ☐ Keep all the doors on the boiler closed
- ☐ Shut down the boiler according to procedure
- ☐ Ventilate the room where the boiler is installed
- ☐ Close the fire door and doors to living areas

Recommendation: Do not install smoke alarms and carbon monoxide detectors near the system.

2.9.3 Fire in the system



DANGER

In case of fire in the system:

Risk of death by fire and poisonous gases

Emergency procedure in case of fire:

- ☐ Leave the boiler room
- ☐ Close the doors
- ☐ Inform the fire department

3 Notes for operating a heating system

Carrying out modifications to the system and changing or disabling safety equipment is prohibited.

Always comply with all fire, building and electrical regulations when installing or operating the system, in addition to following the operating instructions and mandatory regulations that apply in the country in which the tank is operated.

3.1 Installation and approval of the heating system

The boiler should be operated in a closed heating system. The following standards govern the installation:

Note on standards

EN 12828 - Heating Systems in Buildings

NOTICE! Each heating system must be officially approved.

The appropriate supervisory authority (inspection agency) must always be informed when installing or modifying a heating system, and authorisation must be obtained from the building authorities:

Austria: report to the construction authorities of the community or magistrate

Germany: report new installations to an approved chimney sweep / the building authorities.

3.2 General information for installation room (boiler room)

Boiler room characteristics

- The floor must be even, clean and dry and have an adequate load-bearing capacity.
- There must not be a potentially explosive atmosphere in the boiler room as the boiler is not suitable for use in potentially explosive environments.
- The boiler room must be frost-free.
- The boiler does not provide any light, so the customer must ensure sufficient lighting in the boiler room in accordance with national workplace design regulations.
- When using the boiler above 2000 metres above sea level you should consult the manufacturer.
- Danger of fire due to flammable materials.
The floor of the boiler room must not be flammable. No flammable materials should be stored near the boiler. Flammable objects (e.g. clothing) must not be put on the boiler to dry.
- Damage due to impurities in combustion air.
Do not use any solvents or cleaning agents containing chlorine and hydrogen halides in the room where the boiler is installed (e.g. chlorination units for swimming pools).
- Keep the air suction opening of the boiler free of dust.

- The system must be protected against the chewing or nesting of animals (e.g. rodents etc.).

Ventilation of the boiler room

Ventilation air for the boiler room should be taken from and expelled directly outside, and the openings and air ducts should be designed to prevent weather conditions (foliage, snowdrifts, etc.) from obstructing the air flow.

Unless otherwise specified in the applicable building regulations for the boiler room, the following standards apply to the design and dimensions of the air ducts:

Note on standards

ÖNORM H 5170 - Construction and fire protection requirements
TRVB H118 - Technical directives on fire protection/prevention

3.3 Room air-independent operation

The PECO has a central air connection on the back of the boiler. If appropriate supply air and flue gas connections are installed, the boiler can be classified according to EN 15035 as a type C₄₂ / type C₈₂ or according to DIBt as a type FC_{42x} / type FC_{52x}.

The conditions for room air-independent operation of the boiler at the installation site must be clarified with the local authority responsible (authority, chimney sweep, ...).

Definitions as per EN 15035

Type C₄ Boiler that is connected via its combustion air supply and flue gas outlet, with a connecting piece that may be supplied, to a shared chimney with a shaft for combustion air supply and a shaft for flue gas outlet. The mouths of the air and flue gas chimney are either concentric or so close to each other that similar wind conditions apply.

NOTICE! Air is supplied by an air and flue gas system!

Type C₈ A boiler that is connected via its combustion air supply and flue gas outlet, with a connecting piece, to a wind protection device and a single or shared chimney.

NOTICE! Air supply via an air supply line that is independent from the chimney system!

NOTICE! This design requires a wind protection device. If a protective grating is fitted, you must ensure that the mesh size is sufficiently large to prevent a significant loss of pressure and/or seal from dirt!


The second index "2" (C₄₂ / C₈₂) indicates type C boilers with a blower fan downstream of the combustion chamber or the heat exchanger.

Definitions as per DIBt

Type FC_{42x} One appliance with flue gas fan for connection to an air/flue system. The combustion air line from the air shaft and the connecting piece to the chimney are part of the appliance.

Type FC_{52x} One appliance with flue gas fan for connection to a chimney. The combustion air line from the air shaft and the connecting piece to the chimney are part of the appliance.

When dimensioning pipe bends in the supply air line you should note that:



The ratio of the radius of curvature (r) to pipe diameter (d) should be greater than 1

$$r:d \geq 1$$

For example:

- Diameter of supply air connection = 60 mm
- Minimum radius of pipe bends = 60 mm

Install the supply air line in as straight a line as possible and over the shortest path. Keep the number of pipe bends to a minimum.

In addition, the following applies: The maximum resistance of the supply air line is 20 Pa!

You can find the necessary dimensions of the supply air connections in the boiler in the technical data sheets.

3.4 Requirements for central heating water

Unless contrary to other national regulations, the latest versions of the following standards and guidelines apply:

Austria:	ÖNORM H 5195	Switzerland	SWKI BT 102-01
Germany:	VDI 2035	:	UNI 8065
		Italy:	

Observe the standards and also follow the recommendations below:

- ☐ Aim for a pH value of between 8.2 and 10.0. If the central heating water comes into contact with aluminium, the pH value must be between 8.0 and 8.5
- ☐ Use prepared water which complies with the standards cited above for filling and make-up water
- ☐ Avoid leaks and use a closed heating system to maintain water quality during operation
- ☐ When filling with make-up water, always bleed the filling hose before connecting, in order to prevent air from entering the system

Advantages of prepared water:

- Complies with the applicable standards
- Less of a drop in output due to reduced limescale build-up
- Less corrosion due to fewer aggressive substances
- Long-term cost savings thanks to improved energy efficiency

Permitted water hardness for the fill and make-up water in accordance with VDI 2035:

Overall heat output	Total hardness at <20 l/kW minimum individual heat output ¹⁾		Total hardness at >20 ≤50 l/kW minimum individual heat output ¹⁾		Total hardness at >50 l/kW minimum individual heat output ¹⁾	
kW	°dH	mol/m³	°dH	mol/m³	°dH	mol/m³
≤50	no demand or		11.2	2	0.11	0.02
	<16.8 ²⁾	<3 ²⁾				
>50 ≤200	11.2	2	8.4	1.5		
>200 ≤600	8.4	1.5	0.11	0.02		
>600	0.11	0.02				
1. From specific system volume (litres nominal capacity/heat output; for multi-boiler systems use the smallest individual heat output) 2. In the case of systems with central heating boilers and for systems with electric heating elements						

Additional requirements for Switzerland

The filling and make-up water must be demineralised (fully purified)

- The water must not contain any ingredients that could settle and accumulate in the system
- This makes the water non-electroconductive, which prevents corrosion
- It also removes all the neutral salts such as chloride, sulphate and nitrate which can weaken corrosive materials in certain conditions

If some of the system water is lost, e.g. during repairs, the make-up water must also be demineralised. It is not enough to soften the water. The heating system must be professionally cleaned and rinsed before filling the units.

Inspection:

- After eight weeks, the pH value of the water must be between 8.2 and 10.0. If the central heating water comes into contact with aluminium, the pH value must be between 8.0 and 8.5
- Yearly. Values must be recorded by the owner

3.5 Notes for using pressure maintenance systems

Pressure maintenance systems in hot-water heating systems keep the required pressure within predefined limits and balance out volume variations caused by changes in the hot-water temperature. Two main systems are used:

Compressor-controlled pressure maintenance

In compressor-controlled pressure maintenance units, a variable air cushion in the expansion tank is responsible for volume compensation and pressure maintenance. If the pressure is too low, the compressor pumps air into the tank. If the pressure is too high, air is released by means of a solenoid valve. The systems are built solely with closed-diaphragm expansion tanks to prevent the damaging introduction of oxygen into the heating water.

Pump-controlled pressure maintenance

A pump-controlled pressure maintenance unit essentially consists of a pressure-maintenance pump, relief valve and an unpressurised receiving tank. The valve releases hot water into the receiving tank if the pressure is too high. If the pressure drops below a preset value, the pump draws water from the receiving tank and feeds it back into the heating system. Pump-controlled pressure maintenance systems with **open expansion tanks** (e.g. without a diaphragm) introduce ambient oxygen via the surface of the water, exposing the connected system components to the risk of corrosion. These systems offer no oxygen removal for the purposes of corrosion control as required by VDI 2035 and **in the interests of corrosion protection should not be used.**

3.6 Use with storage tank

NOTICE

In principle it is not necessary to use a storage tank for the system to run smoothly. However, we recommend that you use the system with a storage tank, as this ensures a continuous supply of fuel in the ideal output range of the boiler.

For the correct dimensions of the storage tank and the line insulation (in accordance with ÖNORM M 7510 or guideline UZ37) please consult your installer or Froling.

⇒ [See "Addresses" \[page 64\]](#)

3.7 Chimney connection/chimney system

EN 303-5 specifies that the entire flue gas system must be designed to prevent, wherever possible, damage caused by seepage, insufficient feed pressure and condensation. Please note in this respect that flue gas temperatures lower than 160K above room temperature can occur in the permitted operating range of the boiler.

NOTICE! Please see the technical data contained in the assembly instructions for further information about standards and regulations as well as the flue gas temperatures when clean and the other flue gas values!

4 Operating the system

4.1 Assembly and initial startup

Assembly, installation and initial startup of the boiler must only be carried out by qualified staff, and these procedures are described in the accompanying assembly instructions.

NOTICE! See assembly instructions for the PECO

NOTICE

Optimum efficiency and efficient, low-emission operation can only be guaranteed if the system is set up by trained professionals and the standard factory settings are observed.

Take the following precautions:

- ☐ Initial startup should be carried out with an authorised installer or with Froling customer services

The individual steps for initial start-up are explained in the operating instructions for the controller

NOTICE! See operating instructions for boiler controller!

The customer is responsible for ensuring the following prior to initial start-up of the system by Froling customer services:

- Electrical installation
- Installation of water pipes
- Connect flue gas including all insulation work
- Work must comply with local fire protection regulations

- It is essential that the electrician who has carried out the installation work is available when starting up the system for the first time to make any changes to the wiring which may become necessary.
- During initial start-up, operating staff are shown how to use the boiler. It is imperative for proper handover of the product that those involved are present as this is a one-off opportunity.

NOTICE

If condensation escapes during the initial heat-up phase, this does not indicate a fault.


- ☐ Tip: If this occurs, clean up using a cleaning rag.

4.2 Switching on the power supply



- ☐ Turn on the main switch
 - There is voltage at all of the boiler's components
 - When the control has completed the system start, the boiler is ready for operation


4.3 Operating the WOS lever



- ☐ Move the cleaning system lever fully in both directions 10-15 times a week
 - The heat exchanger pipes are cleaned

4.4 Operate the boiler using the touch display

4.4.1 Overview of the touch display



A Display of freely selectable information

⇒ See "Select information displays" [page 30]

W Display and change the current user level

⇒ See "Lock display/switch user level" [page 39]

C Display and change the current date/time

⇒ See "Change date and time" [page 34]

D Holiday program

⇒ See "Configure the holiday program" [page 40]

E Chimney sweeper function

⇒ See "Emissions measurement by chimney sweep or regulatory body" [page 59]

F Display of current operating status, boiler ON/OFF

⇒ See "Switch boiler ON/OFF" [page 32]

G View available functions in the quick menu

⇒ See "Quick menu" [page 29]

H Access all system information. No parameters may be changed in the info menu.

I System menu for opening the system settings. All parameters can be displayed and/or edited depending on the user level.

⇒ See "Navigation within the system menu" [page 26]

J Display and change the current boiler mode

⇒ See "Change boiler mode" [page 33]









K	Display icons for using froeling-connect ⇒ See "Display icons for froeling-connect/remote control" [page 26]
L	Brightness sensor for automatically adjusting the brightness of the display
M	LED frame to display the current system status ⇒ See "Status display" [page 25]
N	USB interface for software update (⇒ see operating instructions for the boiler controller) NOTICE! USB interface is for service purposes only and must not be used to load devices or for PC connections!

Status display

The status display indicates the system's operating status:

- GREEN flashing (interval: 5 sec OFF, 1 sec. ON): Boiler off
- GREEN constant: **BOILER SWITCHED ON**
- ORANGE flashing: **WARNING**
- RED flashing: **FAULT**

Control icons

	Confirms values entered; activates parameters
	Discards any values entered without saving; and closes messages
	Back to basic display
	Accesses all system information
	Opens quick menu. Selection of functions depending on user level, configuration and current status.
	Tap to change parameters (dropdown menu or numeric keypad)
	Opens system menu. Menu display depends on user level and configuration
	Back to higher menu level.


Display icons for froeling-connect/remote control

The icons for connection status and remote control are displayed at the top left of the touch display. Tap on these icons to open the “Connection Centre”. In the menu, the connection to froeling-connect as well as the remote control (switching on and off by external users) is activated/deactivated

Status to froeling-connect		Remote control of the boiler	
	froeling-connect is deactivated or not in use		Remote control of the boiler is permitted
	Establishes connection to froeling-connect		Remote control of the boiler is not permitted
	Connection to the froeling-connect server		
	No network connection to froeling-connect		
	No connection to froeling-connect server, ⇒ See "Connection status to "froeling-connect"" [page 26]		

Connection status to "froeling-connect"

The connection status to “froeling-connect” is displayed in the info menu.



- Tap the info menu in the basic display and navigate to the “froeling-connect” menu
 - The connection status is displayed in the lower range (connected, deactivated, ...)


NOTICE! Consult the “froeling-connect” operating instructions for a detailed description of the connection status as well as troubleshooting

Navigation within the system menu















The system menu shows the menus available depending on the user level and the system configuration. Use the right and left arrows to navigate to the individual menus. Tap the corresponding icon to open the menu. Within the individual menus, the status

display is shown with current values. If, for example, several heating circuits are installed, you can use the right and left arrows to navigate to the desired heating circuit.




Tap the respective tab to carry out settings in the menus.

Icon			Tab		
			Status		
					
			Temperatures		
			Times		
			Service		
			General settings		
			Solar heat meter		

Changing parameters




If there is a “pencil” symbol next to a parameter text, the parameter can be edited. Depending on the type of parameter, it can be edited using the numeric keypad or by selecting from a list and then tapping on the “Confirm” symbol.



Change time window


The desired time window can be set in the “Times” tab in the menus of the heating components (heating, water, ...). Up to four time windows are possible per day.

- ☐ Use the left or right arrow to navigate to the desired day of the week
- ☐ Tap the time window or icon under the day of the week
- ☐ Tap on the time window to be changed




- ☐ Use the up and down arrows to set the start and end time and save by tapping on the “Confirm” icon

The time window set is saved for all selected days of the week.



To delete a saved time window, tap on the “Recycle bin” icon next to it.



Quick menu






The quick menu provides different functions depending on the system configuration and system status.

Icon	Description
	Language selection Sets the desired system language: Deutsch – English – Francais – Italiano – Slovenski – Cesky – Polski – Svenska – Espanol – Magyar – Suomi – Dansk – Nederlands – Русский – Srpski – Hrvatski
	Clean the touch display The touch display is locked for 10 seconds, during which time it is possible to clean it without inadvertently changing the settings.
	User level Changes the current user level Code “0” ... Child lock/Lock Code “1” ... Customer
	Extra heating Boiler starts, heating and domestic hot water tank are activated for 6 hours. The mode setting is ignored. CAUTION: The external temperature heating limit set in the "Heating" menu is active and can prevent release of the heating circuits.
	Extra loading One-time extra loading of all available DHW tanks. Afterwards the mode that was previously set becomes active again.
	Error display List of all pending boiler faults and how to eliminate them.


4.4.2 Select information displays

Tapping on the freely selectable information displays in the basic display opens the respective menu. The following options are available depending on the system configuration:


Menu	Selection	Icon	Description
Boiler	Empty ash in		Display of the remaining heating hours until the message "Ash box full, please empty" appears.
	Temperatures		Display of boiler und flue gas temperature
	Calorific value heat exchanger ¹⁾		Display of boiler and flue gas temperature before or after the calorific value heat exchanger.
	Operation hours		Display of the operating hours and the operating hours since last maintenance.
Outside air temperature	Temperatures		Display of the current outside air temperature.
Boiler 2	Temperatures		Display of the temperature of the secondary boiler and the status of the burner relay
Solar	Temperatures		Display of the collector temperature and control of the collector pump.
Pellets	Remaining pellet amount in store room		Display of the remaining amount of pellets in storeroom.
Heating circuit 01 – 18	Temperatures		Display of the actual flow temperature and flow temperature setpoint of the respective heating circuit.
DHW tank 01 – 08	Temperatures		Display of the current DHW tank temperature and control of DHW tank pump of the respective DHW tank.
Storage tank 01 – 04	Temperatures		Display of storage tank temperature, top and bottom
	3 temperature sensors ¹⁾		Display of storage tank temperature, top, middle and bottom.
	4 temperature sensors ¹⁾		Display of storage tank temperature top, store sensor 2, store sensor 3 and bottom.
Circulation pump	Temperatures		Display of the status at the flow sensor (if present) and the current circulation return temperature.

Menu	Selection	Icon	Description
Differential controller	Temperatures		Display of the current temperature from source and recess of the differential regulator
System	CPU/RAM capacity	 	Display of the CPU and RAM capacity in percent

1. This selection merges two tiles together, reducing the maximum number of information displays!



When using more than two store sensors, it is possible to have an information display with storage tank temperatures in accordance with the number of sensors. An information display that spans two areas is used.



4.4.3 Switch boiler ON/OFF

The hydraulic system is controlled in accordance with the mode that is set, regardless of boiler status, ⇒ See "Change boiler mode" [page 33]



Boiler ON


The boiler is activated and starts following a command from the hydraulic system. (Storage tank, heating circuit, domestic hot water...). Heating circuits and domestic hot water tanks are controlled according to the programs and times set.



Boiler OFF

The control follows the boiler shutdown procedure and starts the cleaning cycle. The boiler switches to "Boiler OFF" status. All boiler units are deactivated, heating circuits and domestic hot water tanks are controlled according to the programs and times set, the chamber discharge system remains active.

4.4.4 Change boiler mode




Depending on the type of boiler, there are several modes available which can be changed directly in the basic display of the touch display.

Mode	Icon	Description
Automatic		Supply heating circuits and domestic hot water tanks with heat according to the selected heating times.
Domestic hot water		The domestic hot water tank is supplied with heat within the selected loading times. Heating circuits are switched off, frost protection remains active.
Continuous load		The boiler continuously maintains the selected boiler temperature setpoint and only shuts down for cleaning purposes. Supply heating circuits and domestic hot water tanks with heat according to the selected heating times.


NOTICE! Consult the enclosed operating instructions for the boiler controller for a detailed description of the boiler modes.

4.4.5 Change date and time

Tap on the displayed date and time to change the date and time in the basic display. Use the up and down arrows to adjust the settings and tap on the “Confirm” icon to save.



4.4.6 Change desired DHW tank temperature




- ☐ Tap the information display for the desired DHW tank
- ☐ Adjust the temperature setpoint by tapping on “+” or “-”



NOTICE! If this selection is not configured in the information display in the basic display, open the components in the system menu.

4.4.7 One-time extra loading of an individual DHW tank



- ☐ Tap the information display for the desired DHW tank
- ☐ Tap the mode icon for the DHW tank



- ☐ Tap the "extra loading" icon
 - ➔ One-time loading of DHW tank starts. Once the selected DHW tank temperature setpoint has been reached, loading stops and the icon switches to "automatic".




NOTICE! If this selection is not configured in the information display in the basic display, open the components in the system menu.

4.4.8 One-time extra loading of all existing DHW tanks.

In the case of several DHW tanks, the "extra loading" function in the quick menu is used to start a one-time extra loading of all existing DHW tanks.

⇒ See "Quick menu" [page 29]

4.4.9 Set the heating curve of a heating circuit



A flow temperature is calculated using the heating curve of the heating circuit depending on the outside air temperature and the two adjustable parameters “flow temperature at -10°C outside air temperature” and “flow temperature at $+10^{\circ}\text{C}$ outside air temperature”.

Example:

The heating curve is defined with 60°C (at -10°C outside air temperature) and 40°C (at $+10^{\circ}\text{C}$ outside air temperature). If the current outside air temperature is -2°C , the flow temperature is calculated as 52°C .

Heating circuits without measuring the room temperature are operated using the calculated values. The heating curve must be adapted to influence the room temperature, \Rightarrow See ["Change room temperature \(heating circuit without room temperature sensor\)"](#) [page 37]

When using a room temperature sensor (analogue remote control FRA, room console RBG 3200, room console RBG 3200 Touch, room temperature sensor) it is not necessary to interfere with the heating curve. Any deviation of the actual room temperature to the room temperature setpoint is automatically compensated by increasing/reducing the flow temperature.

When starting up the system it is defined whether the heating circuit is operating as a “high temperature circuit” or a “low temperature circuit”. The following values are set:

High temperature circuit

- Desired flow temperature at -10°C outside air temperature: **60°C**
- Desired flow temperature at $+10^{\circ}\text{C}$ outside air temperature: **40°C**

Low temperature circuit

- Desired flow temperature at -10°C outside air temperature: **40°C**
- Desired flow temperature at $+10^{\circ}\text{C}$ outside air temperature: **30°C**

Reduction of flow temperature

Outside of the set heating times (\Rightarrow See ["Change time window"](#) [page 28]), the setback mode is active and the calculated flow temperature is reduced by the adjustable value “Reduction of flow temperature in setback mode”.


Heating limits

The outside air temperature heat limits are set in the “Temperatures” tab and they activate/deactivate the heating circuit depending on the outside air temperature or time period.

Parameter	Effect
Outside air temperature, at which heating circuit pump switches off in heating mode (default: 18°C)	If the outside air temperature difference rises above the set value, the heating circuit is deactivated. (Pump off, mixing valve closes)
Outside air temperature, at which heating circuit pump switches off in setback mode (default: 7°C)	If the outside air temperature in setback mode (default: 22:00 – 06:00) falls below the set value, the heating circuit is activated (pump on, mixing valve regulated as per heating curve)

4.4.10 Change room temperature (heating circuit without room temperature sensor)


Situation	Effect
Room temperature generally too low	Move heating curve up in parallel. Increase both points on the heating curve by the same temperature level. (see figure 1)
Room temperature on warm days too low, OK on cold days	Change the slope of the heating curve. Increase the temperature level of the heating curve at -10°C (see figure 2)
Room temperature on warm days too high, OK on cold days	Change the slope of the heating curve. Reduce the temperature level of the heating curve at +10 °C (see figure 3)



Depending on the situation, the heating curve can be adapted by tapping “+” or “-” at +/-10°C outside air temperature.

If the heating curve is to be changed, never change the desired point for a high temperature circuit more than 5°C, and never more than 3°C for a low temperature circuit. Once the changes have been made, wait a few days and assess comfort levels before carrying out additional changes.

4.4.11 Change room temperature (heating circuit mit room temperature sensor)



- ☐ Tap information display of the desired heating circuit
- ☐ Tap “+” or “-” to adjust the desired room temperature










NOTICE! If this selection is not configured in the information display in the basic display, open the components in the system menu.

Otherwise, the room temperature can be adjusted directly on the remote control/room console.

4.4.12 Switch heating circuit mode

Tap on the mode icon in the menu of the respective heating circuit to change the mode.

Procedure	Icon	Description	
		OFF	The heating circuit is switched off. Frost protection remains active!
		Auto	The heating circuit is controlled according to the set time program.
		Party	The heating circuit is regulated before the start of the next heating time. To cancel this function prematurely, activate another mode/function.
		Setback mode	The heating circuit is regulated to the set setback temperature until the start of the next heating time. To cancel this function prematurely, activate another mode/function.
		Extra heating	The heating circuit is regulated to the set room temperature with no time limitation. To cancel this function prematurely, activate another mode/function.
		Continuous setback mode	The heating circuit is regulated to the set setback temperature until activation of another mode/function.

4.4.13 Lock display/switch user level

For safety reasons individual parameters are only visible at specific operating levels. To change to another level it is necessary to enter the relevant user code.




- Tap on the icon for the user level in the upper area of the basic display and enter the code.


User level	Icon	Description
Lock (Code "0")		At "Lock" level, only the basic display appears. It is not possible to change parameters.
Customer (Code "1")		Standard user level for normal operation of the controller. All customer-specific parameters are displayed and can be changed.
Installer		Releases parameters to adjust the controller to the system components (if configured). All parameters are available.
Service		

4.4.14 Change the name of the components

The names of the DHW tank, storage tank and heating circuits can be freely selected. A maximum of 20 characters are available for the name.





- Navigate to the "System" menu and open the "Renaming" sub-menu




- Tap the desired component and use the keyboard to rename it

4.4.15 Configure the holiday program

Setting a start and end date in the holiday program determines a time period in which an active heating circuit is regulated for the set setback temperature and in which an activated boiler is not loaded. If Legionella heating is set, it remains active.




If the start date is set in the future, the “suitcase” icon will be highlighted in green.



Once the set start time of the holiday program has been reached, the boiler switches to “holiday” mode

Tap the “suitcase” icon to prematurely end the holiday program. The boiler then switches to the previously activated mode (“water tap” symbol = domestic hot water, “water tap/radiator” symbol = automatic).





4.5 Switch the boiler ON/OFF on the room console

Prerequisite:

- Boiler access rights configured for the room console

If the boiler remote control is also activated (⇒ See ["Display icons for froeling-connect/remote control"](#) [page 26]), the boiler can be switched on and off on the room console.



- Switch the boiler ON/OFF by tapping on the current operating status


4.6 Adjust the pellet consumption counter after filling the store room

4.6.1 Adjust the pellet consumption counter to the fuel

NOTICE! The boiler must be in the “Boiler off / standby” operating status!


To accurately calculate pellet consumption, it is recommended to regularly weigh the amount of pellets fed in at 100% feed rate.

- ☐ Remove the cover and the combustion chamber cover
- ☐ Remove the burn-out tray
 - The burner insert remains in the burner
- ☐ Remove flue ash and clean the combustion chamber and burners
Cleaning the burn-out tray, burner insert and combustion chamber




- ☐ Insert receiving tank with suitable dimensions into the burner

Start the process:



- ☐ In the "Consumption" menu, set the "Start the process for determining the pellet feed rate" parameter to "YES"
 - ➔ Stoker screw feeds pellets to the receiving tank with a fuel feed-in of 100% for several minutes




Once the process is finished:

- ☐ Manually move the pellets away from the feed-in opening into the receiving tank so that none of the pellets fall into the ash chamber below
- ☐ Weigh the receiving tank including pellets on the kitchen scale
- ☐ Subtract the weight of the receiving tank and note the value
- ☐ Empty the pellets into the pellet fuel store
- ☐ Carry out the entire procedure again and note the displayed value once again



- ☐ Tap the information display of the pellet consumption
- ☐ Enter the larger of value of the two measurements in the "Consumption" menu in the "Delivered amount of pellets at 100% feed" parameter


4.6.2 Setting the automatic notification for minimum level



- In the “Consumption” menu, select the “Minimum pellet level fuel storeroom” parameter and enter the desired value

TIP: Select approximately 10% of the fuel store capacity as the value for the minimum level.

When the set minimum level in the pellet store is reached, a message is shown on the boiler display:




- Select and confirm by tapping the “pen” icon
 - No more reminders
 - Reminder in two days
 - Reminder in one week

4.6.3 Resetting the pellet consumption counter

The pellet consumption counter indicates the consumption of pellets in the parameters “Resettable t-counter” and “Resettable kg-counter” in steps of tons or kilograms. Both values are set to “0” by resetting.

Examples of use for the counter:

- Monthly accounting to illustrate seasonal changes in pellet consumption
- Seasonal accounting (e.g. during the winter months) to illustrate annual changes in pellet consumption



- In the “Consumption” menu, set the “RESET counter” to “YES”
 - Values of the parameters “Resettable t-counter” and “Resettable kg-counter” are reset to “0”
 - Parameter “RESET counter” is reset to “NO”

4.7 Checking the fill level of the ash container and emptying if required

The ash container must be emptied at appropriate intervals depending on energy requirements and fuel quality. The grate, burn-out tray and combustion chamber should also be checked at these intervals.

WARNING


When removing the ash container cover during operation:

False air infiltration via the ash screw duct can lead to uncontrolled combustion and the risk of accidents.

Before checking the ash level / emptying the ash container:


- Switch off the boiler by tapping “Boiler off”
 - The boiler follows the shutdown procedure and switches to “Boiler off” status.

4.7.1 Check the fill level of the ash container



- ☐ Open the insulated door
- ☐ Open the locks (A) on the cover by turning anti-clockwise
- ☐ Remove the cover and check the fill level
- ☐ Replace the cover and secure with locks (A)

The message “Reset counter of hours till ashbox full warning” appears on the boiler display:




If the ash container is emptied:

- ☐ Confirm the message by tapping on “YES”
 - The counter of the remaining heating hours is reset to the preset value

If the ash container is not emptied:

- ☐ Close the message by tapping on “NO”
 - The counter of the remaining heating hours remains unchanged

4.7.2 Empty ash container



- ☐ Open the insulated door of the boiler
 - ☐ Open the side fasteners (A) on the ash container and remove the ash container
 - ☐ Close the opening at the rear with the sliding valve and take the ash container to the emptying point
- ➔ ⇒ See "Disposal of the ash" [page 60]

4.8 Switching off the power supply

WARNING

When turning off the main switch in automatic mode:

Serious combustion faults leading to serious accidents are possible.

Before turning off the main switch:

- ☐ Switch boiler off by tapping "Boiler OFF"
 - ➔ The boiler follows the shutdown procedure and switches to "Boiler off" status after the cleaning cycle



- ☐ Turn off the main switch
 - ➔ Boiler controller is switched off
 - ➔ There is no power supply to any of the boiler components

NOTICE! Frost protection function is no longer active!

5 Servicing the system

5.1 General information on servicing



DANGER

When working on electrical components:

Risk of electrocution!

When work is carried out on electrical components:

- ☐ Always have work carried out by a qualified electrician
- ☐ Observe the applicable standards and regulations
 - ➔ Work must not be carried out on electrical components by unauthorised persons



WARNING

When inspecting and cleaning the boiler with the main switch on:

Serious injuries possible due to automatic boiler startup!

Before inspection and cleaning work in/on the boiler:

- ☐ Switch the boiler off by tapping "Boiler off"
The boiler follows the shutdown procedure and switches to "Boiler off" mode
- ☐ Allow the boiler to cool for at least 1 hour
- ☐ Switch off the main switch and take precautions to prevent accidental switching on



WARNING

During inspection and cleaning work on the hot boiler:

Hot parts and the flue gas pipe can cause serious burns!

Take the following precautions:

- ☐ It should be standard practice to wear protective gloves when working on the boiler.
- ☐ Only operate the boiler using the handles provided
- ☐ Before starting work, switch off the boiler and allow it to cool down for at least 1 hour

NOTICE

We recommend that you keep a maintenance book in accordance with ÖNORM M7510 of the Technical Directive for Fire Prevention (TRVB)

⚠ WARNING



Incorrect inspection and cleaning:


Incorrect or insufficient inspection and cleaning of the boiler can cause serious faults in combustion (e.g. spontaneous combustion of carbonisation gases / flash fires) and this can lead to serious accidents and damage!

Take the following precautions:

- ☐ Clean the boiler following the instructions in the instruction manual. Follow the boiler operating instructions.

5.2 Required tools

The following tools are required for carrying out cleaning and maintenance work:



Included in delivery:

1	Furnace tool with bracket
2	Mounting bracket for burner insert (only for boiler type 25-35)
3	Socket wrench AF 13
4	Cleaning brush (Ø 41 x 1000) for cleaning the heat exchanger

Not included:

5	Screwdriver set (Philips, flat head, Torx T20, T25, T30)
6	Small brush or cleaning brush
7	Ash vacuum

5.3 Maintenance work by the operator

- ☐ Regular cleaning of the boiler extends its life and is a basic requirement for smooth running.
- ☐ Recommendation: use an ash vacuum for cleaning.

5.3.1 Inspection

Checking the system pressure



- ☐ Check the system pressure on the pressure gauge
 - The value must be 20% above the pre-stressed pressure of the expansion tank
- NOTICE! Check that the position of the pressure gauge and rated pressure of the expansion tank match your installer's specifications!**

If the system pressure decreases:

- ☐ Top up with water

NOTICE! If this happens frequently, the seal of the heating system is faulty! Inform your installer

If large pressure fluctuations are observed:


- ☐ Ask an expert to inspect the expansion tank

Checking the safety valve



- ☐ Check the seal of the safety valve regularly and ensure that the valve is not dirty
- NOTICE! Inspection work must be carried out in accordance with the manufacturer's instructions.**

Checking the quick vent valve




- ☐ Regularly check all the quick vent valves on the entire heating system for leaks
 - If any liquid is leaking, replace the quick vent valves

NOTICE! The vent cap (A) must be loose (screw on approx. two revolutions) to ensure correct functioning.


5.3.2 Cleaning

- ☐ Allow the boiler to cool for at least one hour
- ☐ Activate service as described in the following

In service mode the induced draught rotates at low speed. The cleaning process is thus supported by the suctioning up of the stirred up ash.




- ☐ Tap on "Service mode" in the quick menu




- ☐ The "Cleaning" mode is activated in accordance with boiler-specific processes
 - As soon as this state is displayed, the cleaning process may begin.

Cleaning the burn-out tray, burner insert and combustion chamber



- ☐ Open the insulated door
- ☐ Lift up to unhook the cover of the combustion chamber
- ☐ Dismantle the combustion chamber cover using a box wrench combustion chamber
 - The box wrench is attached in tool clamp (A) on the inside of the insulated door



- ☐ Remove burn-out tray and burner insert

For boiler type 25-35:

- Rotate components 90° to facilitate dismantling.
- Use mounting bracket (A)

- ☐ Clean burn-out tray and burner insert
- ☐ Clean the top side and interior surfaces of the burner
- ☐ Remove deposits from the opening of the igniter tube


5.3.3 Periodic inspection and cleaning

The boiler must be inspected and cleaned at appropriate intervals depending on the operating hours and fuel quality.


Inspection and cleaning must be repeated after not more than 2500 operating hours or at least once a year. For less efficient fuels (e.g. high ash content) this work needs to be carried out more frequently.

Clean the induced draft fan


- ☐ Start the shutdown procedure by tapping “Boiler OFF”
- ☐ Switch off the boiler at the main switch and let cool down for at least one hour



- ☐ Open the insulated door and undo the safety screws located behind it
- ☐ Lift the cover slightly and remove it from the front




- ☐ Remove the plug connection from the induced draught fan
- ☐ Remove the thermal insulation on the induced draught fan




- ☐ Dismantle the induced draught unit housing including ID fan
- ☐ Carefully clean the induced draught unit housing and impeller on the ID fan


Clean the heat exchanger and WOS springs



- ☐ Remove the pipe locking pin from the linking plate
- ☐ Lift out the linking plates including WOS springs
- ☐ Clean the WOS springs



- ☐ Use a brush to clean the flue gas collection chamber, opening to the flue gas pipe and heat exchanger pipes
- ☐ Remove any soot which has fallen in
 - **TIP:** Use an ash vacuum
- ☐ Dismantle the ash removal console at the front



- ☐ Remove any accumulated soot using a flat scraper

Cleaning the flue gas pipe

- ☐ Remove the inspection cover on the connecting pipe
- ☐ Clean the connecting pipe between the boiler and chimney with a chimney sweep's brush
 - Depending on the layout of the flue gas pipes and the chimney draught cleaning, yearly may not be enough!

Checking the draught controller flap

- ☐ Check that the draught controller flap moves freely

5.4 Maintenance work by technicians

CAUTION

If maintenance work is carried out by untrained personnel:

Risk of personal injury and damage to property!

The following applies for maintenance:

- ☐ Observe the instructions and information in the manuals
- ☐ Only allow appropriately qualified personnel to work on the system

Only qualified staff are permitted to carry out maintenance work in this chapter:

- Heating technicians / building technicians
- Electrical installation technicians
- Froling customer services

The maintenance staff must have read and understood the instructions in the documentation.

NOTICE! We recommend a yearly inspection by Froling customer services or an authorised partner (third party maintenance).

Regular maintenance and servicing by a heating specialist will ensure a long, trouble-free service life for your heating system. It will ensure that your system stays environmentally-friendly and operates efficiently and cost-effectively.


In the course of this maintenance the entire system is inspected and optimised, particularly regulation and control of the boiler. The emission measurement carried out can also be used to draw conclusions about the combustion performance of the boiler. For this reason, FROLING offers a service agreement, which optimises operating safety. Please see the details in the accompanying guarantee certificate.

Your Froling customer service office will also be happy to advise you.


NOTICE

All national and regional regulations relating to regular testing of the system must be observed. Please be advised that, in Austria, commercial systems with a rated heat output of 50 kW or more must be regularly tested at yearly intervals in accordance with the Heating Plant Regulations (Feuerungsanlagen-Verordnung).

5.4.1 Checking and cleaning the combustion grate



- ☐ Undo the screws on the top and remove the side panel




With ignition cartridge:

- ☐ Pull the hooks (A) on the spring cotter to the side and pull out the ignition cartridge

With glow igniters:


- ☐ Loosen spring clip (B) and pull out glow igniters




- ☐ Dismantle the entire grate unit
 - Pay attention to the cable for the grate unit
- ☐ Thoroughly clean the combustion grate, remove any dirt from the air openings using a screwdriver

NOTICE! Small cracks and slight deformations on the grate are not indicative of a fault. After a thorough cleaning, the grate can be installed again.

5.4.2 Cleaning the measurement line of the underpressure controller




- ☐ Undo the screws on the front cover plate
- ☐ Unlock cover plate to the right and lift off to the front




- ☐ Loosen the twin wire clamps (A) with pliers and remove the measurement line (B)
- ☐ Clean the measurement line with gentle compressed air
 - **WARNING!** Do not blow compressed air into the differential pressure transmitter!
It may damage the measuring device
- ☐ After cleaning, insert the measurement line into the measuring nipple and the "P2" connection of the differential pressure transmitter and attach using twin wire clamps

5.4.3 Cleaning the Lambda probe



- ☐ Remove the cover plate on the boiler flow
- ☐ Press the thermal insulation behind it slightly downwards



- ☐ Carefully remove the Lambda probe (1) and plastic bushing (2)
 - Pay attention to the cables of the Lambda probe!
- ☐ Carefully remove impurities from the measuring ports with a fine brush and ash vacuum
 - Hold the Lambda probe with the tip downwards so that deposits can fall out of the measuring ports
- ☐ Check the plastic bushing (2) for dirt and cracks, replace if necessary
 - **IMPORTANT:** The seal surface of the plastic bushing must lie flat after assembly

CAUTION:

- Do not clean the Lambda probe with compressed air
- Do not use chemical cleaning agents (brake cleaner, etc.)
- Careful handling of the Lambda probe, no “tapping” or cleaning with a wire brush

5.5 Emissions measurement by chimney sweep or regulatory body

Various legal regulations stipulate that heating systems must be inspected periodically. In Germany this is regulated by the First Federal Emissions Protection Ordinance (BimSchV) in the last amended version, and in Austria by various state laws.


The following minimum requirements must be met by the operator of the system for a successful measurement:

- ☐ Ensure there is adequate fuel
 - Only use fuels of high quality which meet the requirements as stipulated in the boiler operating instructions ("Permitted fuels" chapter)
- ☐ Ensure that there is adequate heat consumption on the day of the measurement (e.g. storage tank must be able to take heat for the duration of the measurement)
- ☐ There must be a suitable measuring port in the straight flue gas pipe for the measurement. The measuring port must be twice the flue gas pipe diameter away from the last upstream bend.
 - If the measuring port is not correctly positioned, the measuring result will be distorted

5.5.1 Switch on the system


When the cleaning is complete:

- ☐ Reassemble all dismantled components in reverse order and check for tightness and correct installation



- ☐ Turn on the main switch
 - When the control has completed the system start, the boiler is ready for operation
- ☐ Switch the boiler on by tapping "Boiler ON"
 - Automatic mode is active. The heating system is controlled via the controller according to the selected mode in automatic mode

5.5.2 Start emissions measurement



- ☐ Activate the “Chimney-sweep mode” icon
- ☐ Select the desired time from the menu:

immediately	<input type="checkbox"/> Specify the type of measurement (nominal load / partial load) <ul style="list-style-type: none"> ➤ The flue gas temperature and residual oxygen content should have stabilised approximately 20 minutes after activation ➤ The display will indicate that the boiler is ready for measurement as soon as all the conditions for the measurement are fulfilled
Enter target date	<input type="checkbox"/> Enter the time of measurement (date and time) <ul style="list-style-type: none"> ➤ The boiler will follow the shutdown procedure before the start of the measurement according to the time lock and will not start up again until the set time ➤ NOTICE! The boiler starts 30 minutes before the start of the measurement and is already ready for measurement at the set time!

5.6 Replacement parts

With Froling original replacement parts in your system, you are using parts that match perfectly. As the parts fit together so well, installation times are shortened and a long service life is maintained.

NOTICE

Installing non-original parts will invalidate the guarantee.

- ☐ Only replace components or parts with original replacement parts.

5.7 Disposal information

5.7.1 Disposal of the ash

- Austria:** ☐ dispose of ash in accordance with the Waste Management Act (AWG)
- Other countries:** ☐ dispose of ash in accordance with local regulations

5.7.2 Disposal of system components

- ☐ Ensure that they are disposed of in an environmentally friendly way in accordance with waste management regulations in the country (e.g. AWG in Austria)
- ☐ You can separate and clean recyclable materials and send them to a recycling centre.

6 Troubleshooting

6.1 General fault with power supply

Error characteristics	Cause of error	Elimination of error
Nothing is shown on the display	General power failure	
No power to the controller	Main switch is turned off FI-protective circuit breaker, power line protection or SPS power line protection tripped	Turn on the main switch Switch on the protective circuit breaker

6.1.1 Behaviour of system after a power failure

When the power supply has been restored, the boiler returns to the previous mode and is controlled according to the specified program.

- ☐ After a power failure, check whether the STL (high-limit thermostat) has tripped.
- ☐ Keep the doors of the boiler closed during and after the power failure, at least until the induced draught fan automatically starts up again.

EXCEPTION:

If the boiler operating status was "Heating up", "Pre-heating" or "Ignition" before the power failure, the boiler follows the shutdown procedure and cleaning commences. Only then does the boiler switch to "Preparation" operating status and the system starts up again.

6.2 Excessive temperature

The high-limit thermostat (STL) shuts down the boiler when it reaches a temperature of max. 100°C. The pumps continue to run.



Once the temperature falls below approx. 75°C, the STL can be unlocked mechanically:

- ☐ Unscrew the cap on the STL (high-limit thermostat)
- ☐ Unlock the STL by pressing with a screwdriver

6.3 Faults with fault message

If a fault has occurred and has not yet been cleared:

- ☐ Status LED indicates the nature of the fault
 - Orange flashing: Warning
 - Red flashing: Error or alarm
- ☐ A fault message is shown on the display

The term "fault" is a collective term for warnings, errors and alarms. The boiler reacts differently to the three types of message:


WARNING	In case of warnings the boiler initially continues controlled operation, giving the option of resolving the error quickly to prevent a shutdown.
ERROR	The boiler follows the shutdown procedure and remains in "Boiler off" status until the problem is resolved.
ALARM	An alarm triggers a system emergency stop. The boiler shuts down immediately, the heating circuit controller and pumps remain active.

6.3.1 Procedure for fault messages

If a fault occurs on the boiler, it will be shown on the display.


If the fault is acknowledged, although it has not been rectified, the window with the associated fault can be reopened as follows:

Open error display



The error display lists all current faults

- ☐ Open by tapping the listed fault
- ☐ The "Message" tab displays the current fault.
- ☐ Press the "Error resolution" tab to view possible causes and troubleshooting procedures



- ☐ Tap the Cancel icon to close the current fault and display the fault list
- ☐ Tap the Cancel icon again and confirm that you have read all of the errors to return to the basic display
 - ➔ The boiler is in the previously set mode

7 Appendix

7.1 Addresses

7.1.1 Address of manufacturer

FRÖLING
Heizkessel- und Behälterbau GesmbH

Industriestraße 12
A-4710 Grieskirchen
AUSTRIA

TEL 0043 (0)7248 606 0
FAX 0043 (0)7248 606 600
EMAIL info@froeling.com
INTERNET www.froeling.com

Customer service

Austria	0043 (0)7248 606 7000
Germany	0049 (0)89 927 926 400
Worldwide	0043 (0)7248 606 0

7.1.2 Address of the installer

<div>Stamp</div>
