

froling

Installation instructions

Firewood boiler S4 Turbo (F)



Translation of original German version of installation instructions for technicians.

Read and follow all instructions and safety instructions.
All errors and omissions excepted.



M0972024_en | Edition 12/06/2024

1 General	4
1.1 About this manual	4
1.2 Operating principle	4
1.3 Disposal of packaging materials	5
2 Safety	6
2.1 Hazard levels of warnings	6
2.2 Qualification of assembly staff	7
2.3 Personal protective equipment for assembly staff	7
3 Design Information	8
3.1 Overview of standards	8
3.1.1 General standards for heating systems	8
3.1.2 Standards for structural and safety devices	8
3.1.3 Standards for heating water	8
3.1.4 Regulations and standards for permitted fuels	9
3.2 Installation and approval	9
3.3 Installation site	9
3.4 Chimney connection/chimney system	10
3.4.1 Connection line to the chimney	11
3.4.2 Measuring port	12
3.4.3 Draught limiter	12
3.4.4 Electrostatic particle separator	13
3.5 Combustion air	14
3.5.1 General requirement	14
3.5.2 Room air-independent operation	14
3.6 Domestic hot water	16
3.7 Pressure maintenance systems	18
3.8 Storage tank	18
3.9 Return lift	20
3.10 Boiler ventilation	20
4 Technology	21
4.1 Dimensions, S4 Turbo 22-40	21
4.2 Dimensions, S4 Turbo 50-60	22
4.3 Components and connections	23
4.4 Note on SP Dual return feed connection	23
4.5 Technical specifications	24
4.5.1 S4 Turbo 22-28	24
4.5.2 S4 Turbo 32 - 40	26
4.5.3 S4 Turbo 50 - 60	27
4.5.4 Boiler data for planning the flue gas system	29
4.5.5 Data for planning a backup power supply	30
5 Transport and storage	31
5.1 Delivery configuration	31
5.2 Temporary storage	31
5.3 Positioning	32
5.4 Positioning at the installation site	33
5.4.1 Remove boiler from pallet	33
5.4.2 Operating and maintenance areas of the equipment	34
6 Assembly	36

6.1	Required tools and equipment	36
6.2	Accessories supplied	36
6.3	Before Installation	37
6.3.1	Changing door stops (as needed).....	37
6.3.2	Checking the seal on the doors	39
6.3.3	Adjusting the doors	40
6.4	Assembling the S4 Turbo 22-40.....	41
6.4.1	Assembly overview	41
6.4.2	Fit the induced draught fan	46
6.4.3	Installing the pneumatic rods for the primary and secondary air	46
6.4.4	Installing the Lambda probe, flue gas temperature sensor and immersion sleeve.....	49
6.4.5	Installing the insulation.....	50
6.4.6	Installing the control	51
6.4.7	Installing the back panel	51
6.4.8	Installing the insulated door	52
6.4.9	Attaching the controller	54
6.4.10	Installing the servo-motors.....	55
6.4.11	Installing the WOS lever	56
6.5	Assembling the S4 Turbo 50-60.....	58
6.5.1	Assembly overview	58
6.5.2	Installing the pneumatic rods for the primary and secondary air	61
6.5.3	Installing the insulation.....	64
6.5.4	Installing the control	65
6.5.5	Installing the back panel	65
6.5.6	Installing the insulated door	66
6.5.7	Attaching the controller	67
6.5.8	Install the Lambda probe, sensor and thermal discharge valve.....	68
6.5.9	Installing the servo-motors.....	70
6.5.10	Installing the induced draught fan	71
6.5.11	Installing the WOS lever	73
6.6	Electrical connection and wiring.....	73
6.6.1	Board overview	75
6.6.2	Connect the firewood boiler components.....	76
6.6.3	Potential equalisation.....	77
6.7	Concluding work.....	78
6.7.1	Positioning the boiler stickers	79
6.7.2	Insulate the connection line	79
6.7.3	Install the brackets for accessories.....	80
6.8	Hydraulic connection.....	81
7	Start-up.....	82
7.1	Before commissioning / configuring the boiler	82
7.2	Initial startup.....	83
7.2.1	Permitted fuels	83
7.2.2	Fuels permitted under certain conditions	85
7.2.3	Non-permitted fuels.....	85
7.2.4	Heating up for the first time	85
8	Decommissioning	87
8.1	Mothballing.....	87
8.2	Disassembly.....	87
8.3	Disposal	87
9	Appendix.....	88
9.1	Pressure equipment regulation	88

1 General

Thank you for choosing a quality product from Fröling. The product features a state-of-the-art design and conforms to all currently applicable standards and testing guidelines.

Please read and observe the documentation provided and always keep it close to the system for reference. Observing the requirements and safety information in the documentation makes a significant contribution to safe, appropriate, environmentally friendly and economical operation of the system.

The constant further development of our products means that there may be minor differences from the pictures and content. If you discover any errors, please let us know: doku@froeling.com.

Subject to technical change.

Issuing a delivery certificate

The EC Declaration of Conformity is only valid in conjunction with a delivery certificate, which has been filled in correctly and signed as part of the commissioning process. The original document remains at the installation site. Commissioning installers or heating engineers are requested to return a copy of the delivery certificate together with the guarantee card to Fröling. On commissioning by FROLING Customer Service the validity of the delivery certificate will be noted on the customer service record.

1.1 About this manual

These installation instructions contain information for the following sizes of S4 Turbo boilers:

22, 28, 32¹⁾, 34, 40, 50, 60;

1) S4 Turbo 32y available only in Italy;





1.2 Operating principle

The Fröling S4 Turbo is a wood boiler for the non-condensing combustion of firewood. The fuel loading chamber is filled with fuel via the fuel loading door located behind the heat insulated door on the front of the boiler. The combustion grate, through which the combustion gases are sucked into the combustion chamber by the induced draught fan, is located below the fuel loading chamber. When the induced draught fan is used, the combustion air around the pre-heating chamber door is sucked in and channelled to the fuel via regulating flaps on the side air boxes (primary and secondary air). The boiler water and flue gas temperature are regulated by the induced draught fan. The primary air is used to adjust the boiler to the fuel and set the required output. The secondary air is used to set the combustion performance by way of the Lambda probe and servo-motor. The flue gas travels through the heat exchanger to the flue gas outlet. In order to optimise heat transfer and for cleaning purposes, the heat exchanger pipes are fitted with an Efficiency Optimisation System (WOS), which can be operated using a lever or activated via a drive. The ash deposits at the bottom of the combustion chamber and below the heat exchanger pipes can be removed via the combustion chamber door on the front of the boiler.

1.3 Disposal of packaging materials

All packaging materials should be disposed of in accordance with the relevant regulations. In addition, check the regulations for correct disposal applicable in your local area.

Data under the identification system of Directive 97/129/EC:

Identification code / Material		Disposal information
	Corrugated cardboard	Paper collection
	Wood	Check the regulations for correct disposal applicable in your local area
	Low Density Polyethylene (LDPE)	Plastics collection
	Expanded polystyrene	Plastics collection

2 Safety

2.1 Hazard levels of warnings

This documentation uses warnings with the following hazard levels to indicate direct hazards and important safety instructions:

DANGER

The dangerous situation is imminent and if measures are not observed it will lead to serious injury or death. You must follow the instructions!

WARNING

The dangerous situation may occur and if measures are not observed it will lead to serious injury or death. Work with extreme care.

CAUTION

The dangerous situation may occur and if measures are not observed it will lead to minor injuries.

NOTICE

The dangerous situation may occur and if measures are not observed it will lead to damage to property or pollution.

2.2 Qualification of assembly staff

CAUTION



Assembly and installation by unqualified persons:

Risk of personal injury and damage to property

During assembly and installation:

- ☐ Observe the instructions and information in the manuals
- ☐ Only allow appropriately qualified personnel to work on the system

Assembly, installation, initial startup and servicing must only be carried out by qualified personnel:

- Heating technicians/building technicians
- Electrical installation technicians
- Froling customer services

The assembly staff must have read and understood the instructions in the documentation.

2.3 Personal protective equipment for assembly staff

You must ensure that staff have the protective equipment specified by accident prevention regulations!



- During transport, erection and installation:
 - wear suitable work wear
 - wear protective gloves
 - wear safety shoes (min. protection class S1P)

3 Design Information

3.1 Overview of standards

Perform installation and commissioning of the system in accordance with the local fire and building regulations. Unless contrary to other national regulations, the latest versions of the following standards and guidelines apply:

3.1.1 General standards for heating systems

EN 303-5	Boilers for solid fuels, manually and automatically fed combustion systems, nominal heat output up to 500 kW
EN 12828	Heating systems in buildings - design of water-based heating systems
EN 13384-1	Chimneys - Thermal and fluid dynamic calculation methods Part 1: Chimneys serving one appliance
ÖNORM H 5151	Planning of central hot water heating systems with or without hot water preparation
ÖNORM M 7510-1	Guidelines for checking central heating systems Part 1: General requirements and one-off inspections
ÖNORM M 7510-4	Guidelines for checking central heating systems Part 4: Simple check for heating plants for solid fuels

3.1.2 Standards for structural and safety devices

ÖNORM H 5170	Heating installation - Requirements for construction and safety engineering, as well as fire prevention and environmental protection
--------------	--

3.1.3 Standards for heating water

ÖNORM H 5195-1	Prevention of damage by corrosion and scale formation in closed warm water heating systems at operating temperatures up to 100°C (Austria).
VDI 2035	Prevention of damage hot water heating systems (Germany)
SWKI BT 102-01	Water quality for heating, steam, cooling and air conditioning systems (Switzerland)
UNI 8065	Technical standard regulating hot water preparation. DM 26.06.2015 (Ministerial Decree specifying the minimum requirements) Follow the instructions of this standard and any related updates. (Italy)

3.1.4 Regulations and standards for permitted fuels

1. BImSchV	First Order of the German Federal Government for the implementation of the Federal Law on Emission Protection (Ordinance on Small and Medium Combustion Plants) in the version published on 26 January 2010, BGBl. JG 2010 Part I No. 4.
EN ISO 17225-3	Solid bio-fuel - Fuel specifications and classes Part 3: Wood briquettes for non-industrial use
EN ISO 17225-5	Solid bio-fuel - Fuel specifications and classes Part 5: Firewood for non-industrial use

3.2 Installation and approval

The boiler should be operated in a closed heating system. The following standards govern the installation:

Note on standards

EN 12828 - Heating Systems in Buildings

IMPORTANT: Every heating system must be officially approved.

The appropriate supervisory authority (inspection agency) must always be informed when installing or modifying a heating system, and authorisation must be obtained from the building authorities:

Austria: report to the construction authorities of the community or magistrate

Germany: report new installations to an approved chimney sweep / the building authorities.

3.3 Installation site


Requirements for the load bearing substrate:

- Flat, clean and dry
- Non-combustible and with sufficient load-bearing capacity

Conditions at the installation site:

- Protecting the system against frost
- Sufficiently well lit
- Free of explosive atmospheres such as flammable substances, hydrogen halides, cleaning agents and consumables
- Installation at altitude higher than 2000 metres above sea level only after consultation with the manufacturer
- The system must be protected against gnawing and nesting by animals (such as rodents)
- No flammable materials in proximity to the system
- Observe national and regional regulations regarding the installation of smoke detectors and carbon monoxide detectors

3.4 Chimney connection/chimney system



- | | |
|---|--|
| 1 | Connection line to the chimney |
| 2 | Measuring port |
| 3 | Draught limiter |
| 4 | Explosion flap (for automatic boilers) |
| 5 | Thermal insulation |

NOTICE! The chimney must be authorised by a smoke trap sweeper or chimney sweep.

The entire flue gas system (chimney and connection) must be laid out as per ÖNORM / DIN EN 13384-1 or ÖNORM M 7515 / DIN 4705-1.

The flue gas temperatures (for clean systems) and additional flue gas values can be found in the table in the technical data.



Local regulations and other statutory regulations are also applicable.

EN 303-5 specifies that the entire flue gas system must be designed to prevent, wherever possible, damage caused by seepage, insufficient feed pressure and condensation. Please note within the permissible operating range of the boiler flue gas temperatures lower than 160K above room temperature may occur.

3.4.1 Connection line to the chimney

Requirements for the connection line:

- this should be as short as possible and follow an upward incline to the chimney (30 - 45° recommended)
- thermally insulated

MFeuV ¹⁾ (Germany)	EN 15287-1 and EN 15287-2
 <p>[mm]</p>	 <p>[mm]</p>
<p>1. Observe the fire regulations of the respective federal state</p> <p>2. Component made of flammable material</p> <p>3. Nonflammable insulating material</p> <p>4. Radiation shield with rear ventilation</p>	

Minimum distance from flammable substances as per MFeuV¹⁾ (Germany):

- 400 mm excluding thermal insulation
- 100 mm if at least 20 mm thermal insulation is installed


Minimum distance from flammable materials as per EN 15287-1 and EN 15287-2:

- 3 x nominal diameter of connection line, but at least 375 mm (NM)
- 1.5 x nominal diameter of connection line for radiation shield with rear ventilation, but at least 200 mm (NM)

NOTICE! The minimum distances must be observed in accordance with the standards and guidelines applicable in the region

3.4.2 Measuring port

For emissions measurement on the system, a suitable measuring port must be installed in the connection line between the boiler and chimney system.



Upstream of the measuring port (M) there should be a straight run-in section with a length about twice the diameter (D) of the connection line. Downstream of the measuring port (M) there should be a straight run-out section with a length about the diameter (D) of the connection line. The measuring port must remain closed whenever the system is in operation.

The diameter of the measuring probe used by Froling customer service is 14 mm. To avoid measuring errors due to the ingress of false air, the diameter of the measuring port must not exceed 21 mm.

3.4.3 Draught limiter


We generally recommend the installation of a draught limiter. If the values for the maximum permissible feed pressure stated in the section “Data for designing the flue gas system” are exceeded, a draught limiter must be installed.

NOTICE! For boilers with an electrostatic particle separator, the installation of a draught limiter is mandatory.

NOTICE! Install the draught limiter directly under the mouth of the flue duct, as there is persistent under-pressure at this point, which largely prevents the escape of dust from the draught limiter.

3.4.4 Electrostatic particle separator

For reduction in the emissions an electrostatic particle separator may optionally be installed in the flue gas line.



For planning and installation, comply with the following points:

- Position the measuring port (M) downstream of the electrostatic particle separator (E) as specified in the instructions
 ➔ ["Measuring port" \[► 12\]](#)
- Locate the electrostatic particle separator in accordance with the planning for the flue gas system
- Install the electrostatic particle separator in accordance with the manufacturer's instructions supplied

3.5 Combustion air

3.5.1 General requirement

For safe operation, the boiler requires around 1.5 - 3.0 m³ of combustion air per kW nominal heat output and operating hour. The air supply can be provided by free ventilation (e.g. windows, air shaft), mechanical ventilation from outside or, if necessary, from the group of rooms.


The boiler is operated depending on the room air, whereby the combustion air is taken from the installation site.

A suitable air supply must ensure that no impermissible under-pressure greater than 4 Pa is created at the installation site. The use of safety devices (under-pressure monitoring system) may be necessary, particularly if the boiler is operated concurrently with air-suction systems (such as an extractor fan).

Local **NOTICE! Safety equipment and conditions for the operation of the boiler (room air-dependent / room air-independent) must be clarified with the local authority (authority, chimney sweep, ...).**

3.5.2 Room air-independent operation

The combustion air is taken from the installation site. The unpressurised flow of the required air quantity must be ensured accordingly.



- | | |
|---|--|
| 1 | Boiler in room air-dependent operation |
| 2 | Air extraction system (such as centralised dust extraction system, room ventilation) |
| 3 | Under-pressure monitoring system |
| 4 | Combustion air supply from outside |

The minimum cross-sectional area of the supply air opening from outside depends on the nominal heat output of the boiler.

Austria	400 cm ² net minimum cross-sectional area plus 4 cm ² for every kW of nominal heat output above 100 kW
Germany	150 cm ² net minimum cross-sectional area plus an additional 2 cm ² for every further kW of nominal heat output above 50 kW

Examples

Nominal heat output [kW]	Minimum free cross-section [cm ²]									
	10	15	20	30	50	100	150	250	350	500
Austria	400	400	400	400	400	400	600	1000	1400	2000
Germany	150	150	150	150	150	250	350	550	750	1050

Combustion air can also be supplied from other rooms if it can be proven that sufficient combustion air can flow in whilst all mechanical and natural ventilation systems are in operation. The installation site must have a minimum volume in accordance with the applicable regional standards.

Note on standards

Austria:	OIB Guideline 3 - Hygiene, health and environmental protection
Germany:	Model Firing Ordinance (MFeuV)

3.6 Domestic hot water

Unless contrary to other national regulations, the latest versions of the following standards and guidelines apply:

Austria:	ÖNORM H 5195	Switzerland:	SWKI BT 102-01
Germany:	VDI 2035	Italy:	UNI 8065

Observe the standards and also follow the recommendations below:

- ☐ Use prepared water which complies with the standards cited above for filling and make-up water
- ☐ Avoid leaks and use a closed heating system to maintain water quality during operation
- ☐ When filling with top-up water, always vent the filling hose before connecting it, in order to prevent air being drawn into the system
- ☐ Check that the heating water is clear and free of substances that can be deposited as sediments
- ☐ Check that the pH value is between 8.2 and 10.0. If the central heating water comes into contact with aluminium, the pH value must be between 8.2 and 9.0, as specified in VDI 2035
- ☐ The use of fully demineralised filling and top-up water with an electrical conductivity not exceeding 100 µS/cm is recommended by EN 14868
- ☐ After the first 6-8 weeks, check the heating water to ensure that the specified values are being adhered to
- ☐ Unless specified otherwise by regional standards and regulations, perform an annual check on the heating water

Filling and make-up water as well as heating water to VDI 2035 Sheet 1:2021-03:

Total heat output in kW	Total earth alkalis in mol/m ³ (total hardness in °dH)		
	Specific system volume in l/kW heat output ¹⁾		
	≤ 20	20 to ≤40	> 40
≤ 50 specific water content heat generator ≥ 0.3 l/kW ²⁾	none	≤ 3.0 (16.8)	< 0.05 (0.3)
≤ 50 specific water content heat generator < 0.3 l/kW ²⁾ (e.g. circulation water heater) and systems with electric heating elements	≤ 3.0 (16.8)	≤ 1.5 (8.4)	
> 50 to ≤ 200	≤ 2.0 (11.2)	≤ 1.0 (5.6)	
> 200 to ≤ 600	≤ 1.5 (8.4)	< 0.05 (0.3)	
> 600	< 0.05 (0.3)		

1. For calculating the specific system volume, the smallest individual heating capacity is to be used for systems with several heat generators.

2. In systems with several heat generators with different specific water contents, the smallest specific water content is decisive in each case.

Additional requirements for Switzerland

The filling and make-up water must be demineralised (fully purified)

- The water must not contain any ingredients that could settle and accumulate in the system
- This makes the water non-electroconductive, which prevents corrosion
- It also removes all the neutral salts such as chloride, sulphate and nitrate which can weaken corrosive materials in certain conditions

If some of the system water is lost, e.g. during repairs, the make-up water must also be demineralised. It is not enough to soften the water. The heating system must be professionally cleaned and rinsed before filling the units.

Inspection:

- After eight weeks, the pH value of the water must be between 8.2 and 10.0. If the central heating water comes into contact with aluminium, the pH value must be between 8.0 and 8.5
- Annually: values must be recorded by the owner

Advantages of heating water treated in accordance with the standards:

- Less of a drop in output due to reduced limescale build-up
- Less corrosion due to fewer aggressive substances
- Long-term cost savings thanks to improved energy efficiency

Frost protection

When operating the system with frost-protected heat transfer media, the following instructions and ÖNORM H 5195-2 must be observed:

- Antifreeze dosage according to the manufacturer's data sheet
IMPORTANT: If the medium contains too much or too little antifreeze it becomes highly corrosive
- Adding antifreeze reduces the specific heat capacity of the medium; therefore design components (pumps, pipework, etc.) accordingly
- Add frost protection only to heat transfer medium in those areas that may be affected by frost (TIP: system separation)
- Check the antifreeze dosage regularly according to the manufacturer's instructions
- Dispose of frost-protected heat transfer medium at the end of its shelf life and refill the system

3.7 Pressure maintenance systems

Pressure maintenance systems in hot-water heating systems keep the required pressure within predefined limits and balance out volume variations caused by changes in the hot-water temperature. Two main systems are used:

Compressor-controlled pressure maintenance

In compressor-controlled pressure maintenance units, a variable air cushion in the expansion tank is responsible for volume compensation and pressure maintenance. If the pressure is too low, the compressor pumps air into the tank. If the pressure is too high, air is released by means of a solenoid valve. The systems are built solely with closed-diaphragm expansion tanks to prevent the damaging introduction of oxygen into the heating water.

Pump-controlled pressure maintenance

A pump-controlled pressure maintenance unit essentially consists of a pressure-maintenance pump, relief valve and an unpressurised receiving tank. The valve releases hot water into the receiving tank if the pressure is too high. If the pressure drops below a preset value, the pump draws water from the receiving tank and feeds it back into the heating system. Pump-controlled pressure maintenance systems with **open expansion tanks** (e.g. without a diaphragm) introduce ambient oxygen via the surface of the water, exposing the connected system components to the risk of corrosion. These systems offer no oxygen removal for the purposes of corrosion control as required by VDI 2035 and **in the interests of corrosion protection should not be used**.

3.8 Storage tank

Observe the regional regulations for using a storage tank!

Certain subsidy guidelines prescribe compulsory requirements for the installation of storage tanks. Up-to-date information about individual subsidy guidelines can be found at www.froeling.com.

Channelling the heat generated by the Firewood boiler to a storage tank can bring major advantages, such as

- better utilisation of fuel
- more user-friendly operation in terms of reloading intervals
- maximum independence from instantaneous heating requirements
- minimal dirt in boiler and flue gas system

As the boiler's minimum continuous heat output is 30% above the nominal heat output, we as boiler manufacturer are obliged under EN 303-5:2021, Section 4.4.6 to advise that the Firewood boiler S4 Turbo must always be connected to a storage tank with adequate storage capacity.

The storage tank capacity can be calculated using the following formula according to EN 303-5:2021:

$V_{Sp} = 15 T_B \times P_N (1 - 0.3 \times P_H / P_{min})$	
V_{Sp}	Storage tank capacity in litres
P_N	Nominal heat output of boiler in kW
T_B	Burn-off period of boiler in hours ¹⁾
P_H	Heating load of building in kW
P_{min}	Minimum heat output of boiler in kW ²⁾
1. Sample combustion times for various fuels are provided in the technical data	
2. The boiler's minimum output is the lowest value of the output range in the technical data. If there is no minimum heat output specified, use the nominal heat output ($P_{min} = P_N$)	

For the correct dimensions of the storage tank and the line insulation (for instance to ÖNORM M 7510 or guideline UZ37) please consult your installer or Fröling.

Recommended storage tank capacity:

	Unit	S4 Turbo			
		22 - 28	32 - 40	50	60
Recommended storage tank capacity ¹⁾	[l]	2000	2500	3000	3400
1. Values for calculating the capacity can be found in the technical data or the technical data with partial load inspection (if available)					

Certain countries have recommended storage capacities; these are listed below. The specified values apply when the nominal heat output of the boiler corresponds to the heating requirements of the building and a maximum of 50% of the nominal heat output can be dissipated to the building being heated under partial load conditions.

The exact design of the storage tank capacity is in accordance with the locally applicable guidelines and regulations:

<i>Austria</i>	According to the relevant Austrian laws governing energy technology, which are based on Art. 15a B-VG "Agreement on protective measures for small furnaces" (2012): No storage tank is required on manually fed biomass boilers that have been positively tested at both nominal load and partial load (below 50% of nominal load) to ensure they adhere to the emissions limits specified in that agreement.
<i>Germany</i>	The first BImSchV (Ordinance on small and medium-sized heating plants of 26 January 2010, BGBl. I P. 38) stipulates a minimum water heat storage tank volume of 55 litres per kilowatt of rated heat output; a water heat storage tank with a volume of 12 litres per litre of fuel loading chamber is recommended.
<i>Switzerland</i>	In accordance with the Swiss Federal Ordinance on Air Pollution Control (LRV 2018), appendix 3, paragraph 523 "Special requirements for boilers", hand-fed boilers up to 500 kW rated heat output must be fitted with a minimum heat storage tank volume of 12 litres per litre of fuel loading chamber. The volume may not fall below 55 litres per kW rated heat output.

Hot water tank in accordance with Commission Regulation (EU) 2015/ 1189 (Ecodesign Requirements)

The boiler should be operated with a hot water tank. The storage capacity = $45 \times P_r \times (1 - 2.7/P_r)$ or 300 litres, whichever is greater, where the rated heat output of P_r is given in kW. The resulting storage capacity is below the abovementioned recommended storage tank capacity.

3.9 Return lift

If the hot water return temperature is below the minimum return temperature, some of the hot water outfeed will be mixed in.

NOTICE

Risk of dropping below dew point/condensation formation if operated without return temperature control.

Condensation water forms an aggressive condensate when combined with combustion residue, leading to damage to the boiler.

Take the following precautions:

- ☐ Regulations stipulate the use of a return temperature control.
 - ↳ The minimum return temperature is 60 °C. We recommend fitting some kind of control device (e.g. thermometer).

3.10 Boiler ventilation




- ☐ Fit the automatic ventilating valve at the highest point on the boiler or at the ventilation connection (if present).
 - ↳ This ensures that air in the boiler is constantly expelled, thus preventing malfunctions caused by air in the boiler
- ☐ Check that the boiler ventilation is working properly
 - ↳ After installation and periodically according to manufacturer's instructions

Tip: ☐ Fit a vertical pipe as a calming section in front of the automatic ventilating valve in such a way that the ventilating valve is positioned above the water level in the boiler

Recommendation: ☐ Fit a microbubble separator in the pipes to the boiler
 ↳ Follow the manufacturer's instructions!

4 Technology


4.1 Dimensions, S4 Turbo 22-40



Dimension	Description	Unit	22-28	32-40
L1	Length of boiler	mm	1115	1215
L2	Total length incl. induced draught fan		1225	1315
B1	Width, boiler		570	670
B2	Total width incl. actuators		635	735
B3	Overall width incl. automatic ignition (option)		680	780
B4	Distance between flue gas pipe connection and side of boiler		380	430
B5	Distance between flow connection and side of boiler		105	105
B6	Distance between safety heat exchanger connections		60	80
B7	Distance between safety heat exchanger connection and side of boiler		100	115
B8	Distance between drainage connection and side of boiler		285	335
B9	Distance between return connection and side of boiler		465	565
H1	Height of flue gas pipe connection ¹⁾		1705	1705
H2	Total height incl. flue gas pipe nozzle		1600	1600
H3	Height, boiler		1600	1600
H4	Height, safety heat exchanger connection		970	970
H5	Height, return connection		140	140
H6	Height, drainage connection		125	125
H7	Height, flow connection		1360	1360

1. When using the optional flue pipe nozzle for low chimney connections


4.2 Dimensions, S4 Turbo 50-60



Dimension	Description	Unit	50-60
L1	Length of boiler	mm	1215
L2	Total length incl. induced draught fan		1680
B1	Width, boiler		670
B2	Total width incl. actuators		735
B3	Overall width incl. automatic ignition (option)		780
B4	Distance between flue gas pipe connection and side of boiler		470
B5	Distance between flow connection and side of boiler		105
B6	Distance between safety heat exchanger connections		80
B7	Distance between safety heat exchanger connection and side of boiler		115
B8	Distance between drainage connection and side of boiler		335
B9	Distance between return connection and side of boiler		565
H1	Height of flue gas pipe connection ¹⁾		1585
H2	Total height incl. flue gas pipe nozzle		1480
H3	Height, boiler		1600
H4	Height, safety heat exchanger connection		960
H5	Height, return connection		140
H6	Height, drainage connection		120
H7	Height, flow connection		1360


1. When using the optional flue pipe nozzle for low chimney connections

4.3 Components and connections



Item	Description	S4 Turbo 22-60
1	Boiler flow connection	6/4" IT
2	Boiler return connection	6/4" IT
3	Drainage connection	1/2" IT
4	Safety heat exchanger connection	1/2" IT
5	Flue gas temperature sensor connection	6 mm
6	Broadband probe connection	3/4"
7	2x immersion sleeves for: <ul style="list-style-type: none"> ▪ thermal discharge valve (installed by the customer) ▪ Boiler sensor and STL 	1/2"
8	Flue pipe connection	149 mm

4.4 Note on SP Dual return feed connection



4.5 Technical specifications

4.5.1 S4 Turbo 22-28

Description		S4 Turbo (F) ¹⁾	
		22	28
Rated heat output	kW	22	28
Boiler efficiency (NCV)	%	94.3	93.6
Electrical connection	230V / 50Hz / fused C16A		
Weight of boiler incl. insulation and control	kg	645	650
Total boiler capacity (water)	L	115	115
Water pressure drop (ΔT = 10 / 20 K)	mbar	12.0 / 3.1	12.0 / 2.6
Minimum boiler return temperature	°C	60	
Maximum permitted operating temperature		90	
Permitted operating pressure	bar	3	
Airborne sound level	dB(A)	< 70	
Permitted fuel as per EN 17225	Part 5: Firewood class A2 / D15 L50		
Fuel loading door dimensions (width / height)	mm	380 / 360	
Fuel loading chamber capacity	L	145	
Combustion time ²⁾ - beech	h	5.9 – 8.4	4.6 – 6.6
Combustion time ²⁾ - spruce		4.2 – 5.9	3.3 – 4.6
Test book number		PB 026	PB 027
Boiler class as per EN 303-5:2012		5	

1. With regards to the approval of drawings for “S4 Turbo xx F” type boilers, the test results on the heating technology requirements of the “S4 Turbo xx” wood chip boiler according to EN 303-5 can be used.

2. Values specified for combustion time are guideline values at nominal load and will vary depending on water content (15-25%) and fill level (80-100%)

Product data in accordance with the regulations (EU) 2015/1187 and 2015/1189

Model identifier		S4 Turbo (F) ¹⁾	
		22	28
Heating up mode		manual	manual
Condensing boiler		No	No
Solid fuel boiler for combined heat and power		No	No
Combined heating system		No	No
Storage tank volume		↻ "Storage tank" ► 18]	
Preferred fuel		Firewood, moisture content $\leq 25 \%$	
Useful heat delivered at rated heat output (P_n)	kW	22.0	28.0
Fuel efficiency at rated heat output (η_n)	%	86.7	85.3
Auxiliary current consumption at rated heat output ($e_{l_{max}}$)	kW	0.050	0.053
Auxiliary current consumption in standby mode (P_{SB})	kW	0.006	0.010
Energy efficiency class of the boiler		A+	A+
Energy efficiency index (EEI) of the boiler		122	120
Heating space annual rate of use η_s	%	83	82

Model identifier		S4 Turbo (F) ¹⁾	
		22	28
Temperature controller used		Lambdatronic S 3200	
Class of the temperature controller		II	II
Contribution of the temperature controller to the energy efficiency index of a combined system	%	2	2
Energy efficiency index (EEI) of the combined boiler and controller ²⁾		124	122
Energy efficiency class of the combined boiler and controller ²⁾		A+	A+
Annual space heating emissions of dust (PM) ³⁾	mg/m ³	13	16
Annual space heating emissions of gaseous organic compounds (GOC) ³⁾	mg/m ³	5	4
Annual space heating emissions of carbon monoxide (CO) ³⁾	mg/m ³	40	30
Annual space heating emissions of nitrogen oxides (NOx) ³⁾	mg/m ³	130	126
<p>1. With regards to the approval of drawings for "S4 Turbo xx F" type boilers, the test results on the heating technology requirements of the "S4 Turbo xx" wood chip boiler according to EN 303-5 can be used.</p> <p>2. The information on the energy efficiency index EEI of the combined boiler and controller and the energy efficiency class of the combined boiler and controller applies only if the Fröling control components supplied as standard with the respective boiler are used.</p> <p>3. The specified emission values refer to dry flue gas with an oxygen content of 10 % and under standard conditions at 0°C and 1013 millibars. The evaluation values reported are rounded to the nearest whole number. Values labelled with "<" represent the relative detection limit of the measuring methods or measuring device configurations used.</p>			

4.5.2 S4 Turbo 32 - 40

Description		S4 Turbo (F) ¹⁾		
		32 ²⁾	34	40
Rated heat output	kW	32	34	40
Boiler efficiency (NCV)	%	92,6	92.9	93.0
Electrical connection		230V / 50Hz / fused C16A		
Weight of boiler incl. insulation and control	kg	730	735	745
Total boiler capacity (water)	L	175	175	175
Water pressure drop ($\Delta T = 10 / 20 \text{ K}$)	mbar	6.0 / 1.6	6.0 / 1.6	6.0 / 1.6
Minimum boiler return temperature	°C	60		
Maximum permitted operating temperature		90		
Permitted operating pressure	bar	3		
Airborne sound level	dB(A)	< 70		
Permitted fuel as per EN 17225		Part 5: Firewood class A2 / D15 L50		
Fuel loading door dimensions (width / height)	mm	380 / 360	380 / 360	380 / 360
Fuel loading chamber capacity	L	190	190	190
Combustion time ³⁾ - beech	h	4.1 - 6.1	3.9 – 5.7	3.9 – 5.7
Combustion time ³⁾ - spruce		3.0 – 4.3	2.8 – 4.0	2.8 – 4.0
Test book number		PB 115	PB 028	PB 029
Boiler class as per EN 303-5:2012		5	5	5
1. With regards to the approval of drawings for "S4 Turbo xx F" type boilers, the test results on the heating technology requirements of the "S4 Turbo xx" wood chip boiler according to EN 303-5 can be used. 2. S4 Turbo 32 only available in Italy 3. Values specified for combustion time are guideline values at nominal load and will vary depending on water content (15-25%) and fill level (80-100%)				

Product data in accordance with the regulations (EU) 2015/1187 and 2015/1189

Model identifier		S4 Turbo (F)		
		32	34	40
Heating up mode		manual	manual	manual
Condensing boiler		No	No	No
Solid fuel boiler for combined heat and power		No	No	No
Combined heating system		No	No	No
Storage tank volume		↻ "Storage tank" ► 18]		
Preferred fuel		Firewood, moisture content ≤ 25 %		
Useful heat delivered at rated heat output (P_n)	kW	32.0	34.0	40.0
Fuel efficiency at rated heat output (η_n)	%	84.0	84.1	84.2
Auxiliary current consumption at rated heat output ($e_{l_{max}}$)	kW	0.067	0.055	0.055
Auxiliary current consumption in standby mode (P_{SB})	kW	0.014	0.014	0.014
Energy efficiency class of the boiler		A+	A+	A+
Energy efficiency index (EEI) of boiler		118	118	120
Heating space annual rate of use η_s	%	80	81	81
Temperature controller used		Lambdatronic S 3200		
Class of the temperature controller		II	II	II

Model identifier		S4 Turbo (F)		
		32	34	40
Contribution of the temperature controller to the energy efficiency index of a combined system	%	2	2	2
Energy efficiency index (EEI) of the combined boiler and controller ²⁾		120	120	122
Energy efficiency class of the combined boiler and controller ²⁾		A+	A+	A+
Annual space heating emissions of dust (PM) ³⁾	mg/m ³	18	18	16
Annual space heating emissions of gaseous organic compounds (GOC) ³⁾	mg/m ³	4	4	6
Annual space heating emissions of carbon monoxide (CO) ³⁾	mg/m ³	22	21	82
Annual space heating emissions of nitrogen oxides (NOx) ³⁾	mg/m ³	135	122	163
<p>1. With regards to the approval of drawings for "S4 Turbo xx F" type boilers, the test results on the heating technology requirements of the "S4 Turbo xx" wood chip boiler according to EN 303-5 can be used.</p> <p>2. The information on the energy efficiency index EEI of the combined boiler and controller and the energy efficiency class of the combined boiler and controller applies only if the Fröling control components supplied as standard with the respective boiler are used.</p> <p>3. The specified emission values refer to dry flue gas with an oxygen content of 10 % and under standard conditions at 0°C and 1013 millibars. The evaluation values reported are rounded to the nearest whole number. Values labelled with "<" represent the relative detection limit of the measuring methods or measuring device configurations used.</p>				

4.5.3 S4 Turbo 50 - 60

Description		S4 Turbo	
		50	60
Nominal heat output	kW	49.9	60
Boiler efficiency (NCV)	%	93.9	94.9
Electrical connection	230V / 50Hz / fused C16A		
Weight of boiler incl. insulation and control	kg	793	803
Total boiler capacity (water)	L	170	170
Water pressure drop (ΔT = 10 / 20 K)	mbar	15.0 / 5.0	23.0 / 8.0
Minimum boiler return temperature	°C	60	
Maximum permitted operating temperature		90	
Permitted operating pressure	bar	3	
Airborne sound level	dB(A)	< 70	
Permitted fuel as per EN 17225	Part 5: Firewood class A2 / D15 L50		
Fuel loading door dimensions (width / height)	mm	380 / 360	380 / 360
Fuel loading chamber capacity	L	200	200
Combustion time ¹⁾ - beech	h	3.4 – 4.9	2.8 – 4.1
Combustion time ¹⁾ - spruce		2.4 – 3.5	2.0 – 2.9
Test book number		PB 039	PB 040
Boiler class as per EN 303-5:2012		5	
1. Values specified for combustion time are guideline values at nominal load and will vary depending on water content (15-25%) and fill level (80-100%)			

Product data in accordance with the regulations (EU) 2015/1187 and 2015/1189

Model identifier		S4 Turbo	
		50	60
Heating up mode		manual	manual
Condensing boiler		No	No
Solid fuel boiler for combined heat and power		No	No
Combined heating system		No	No
Storage tank volume		↻ "Storage tank" [► 18]	
Preferred fuel		Firewood, moisture content ≤ 25 %	
Useful heat delivered at rated heat output (P_n)	kW	50.0	60.0
Fuel efficiency at rated heat output (η_n)	%	85.3	86.3
Auxiliary current consumption at rated heat output ($e_{l_{max}}$)	kW	0.109	0.162
Auxiliary current consumption in standby mode (P_{SB})	kW	0.014	0.010
Energy efficiency class of the boiler		A+	A+
Energy efficiency index (EEI) of boiler		120	119
Heating space annual rate of use η_s	%	81	81
Temperature controller used		Lambdatronic S 3200	
Class of the temperature controller		II	II
Contribution of the temperature controller to the energy efficiency index of a combined system	%	2	2
Energy efficiency index (EEI) of the combined boiler and controller ¹⁾		122	121
Energy efficiency class of the combined boiler and controller ¹⁾		A+	A+
Annual space heating emissions of dust (PM) ²⁾	mg/m ³	21	26
Annual space heating emissions of gaseous organic compounds (GOC) ²⁾	mg/m ³	6	6
Annual space heating emissions of carbon monoxide (CO) ²⁾	mg/m ³	84	86
Annual space heating emissions of nitrogen oxides (NOx) ²⁾	mg/m ³	165	171
<p>1. The information on the energy efficiency index EEI of the combined boiler and controller and the energy efficiency class of the combined boiler and controller applies only if the Fröling control components supplied as standard with the respective boiler are used.</p> <p>2. The specified emission values refer to dry flue gas with an oxygen content of 10 % and under standard conditions at 0°C and 1013 millibars. The evaluation values reported are rounded to the nearest whole number.</p> <p>Values labelled with "<" represent the relative detection limit of the measuring methods or measuring device configurations used.</p>			

4.5.4 Boiler data for planning the flue gas system

The flue gas performance values listed below should be used for calculation of the fluid dynamics for flue gas systems as specified in the EN 13384 series of standards. The flue gas performance values for the respective outputs are applicable under typical operating conditions when using fuels consistent with the fuel class specified in EN ISO 17225.

Description		S4 Turbo / SP Dual			
		22	28	32 ¹⁾ / 34	40
Flue gas temperature at rated heat output T_{WN} / at the lowest output T_{Wmin}	°C	160 / 110	180 / 130	140 / 110	170 / 130
Volumetric concentration of CO ₂ in the dry flue gas $\sigma(\text{CO}_2)$ at rated heat output	%	12.3			
Flue gas mass flow at rated heat output \dot{m}_N / at the lowest output \dot{m}_{min}	kg/h	58 / 25	76 / 36	90 / 43	108 / 54
	kg/s	0.016 / 0.007	0.021 / 0.010	0.025 / 0.012	0.030 / 0.015
Feed pressure P_{WN} required at the rated heat output / P_{Wmin} required at the lowest output	Pa	8 / 8			
Maximum permissible feed pressure P_{Wmax}	Pa	30			
Feed pressure P_{WO} (blower feed pressure) available at the appliance	Pa	-			
Flue spigot diameter D	mm	149			
Data to be used when for operation independent of the room air					
Supply air connection diameter	mm	-			
Maximum permissible pressure drop P_{Bmax} in the supply air duct	Pa	-			
Combustion air volume at rated heat output	m³/h	-	-	-	-

1. S4 Turbo 32 only available in Italy

1. S4 Turbo 32 only available in Italy


Description		S4 Turbo	
		50	60
Flue gas temperature at rated heat output T_{WN} / at the lowest output T_{Wmin}	°C	150 / 100	170 / 110
Volumetric concentration of CO ₂ in the dry flue gas $\sigma(\text{CO}_2)$ at rated heat output	%	12.3	
Flue gas mass flow at rated heat output \dot{m}_N / at the lowest output \dot{m}_{min}	kg/h	119 / 58	148 / 72
	kg/s	0.033 / 0.016	0.041 / 0.020
Feed pressure P_{WN} required at the rated heat output / P_{Wmin} required at the lowest output	Pa	8 / 8	
Maximum permissible feed pressure P_{Wmax}	Pa	30	
Feed pressure P_{WO} (blower feed pressure) available at the appliance	Pa	-	
Flue spigot diameter D	mm	149	
Data to be used when for operation independent of the room air			
Supply air connection diameter	mm	-	
Maximum permissible pressure drop P_{Bmax} in the supply air duct	Pa	-	
Combustion air volume at rated heat output	m³/h	-	-

4.5.5 Data for planning a backup power supply

Description		Value
Continuous output (single phase)	VA	3680
Nominal voltage	VAC	230 ± 6%
Frequency	Hz	50 ± 2%

5 Transport and storage

5.1 Delivery configuration



Item	Description	Unit	S4 Turbo		
			22-28	34-40	50-60
L1	Length	mm	1270	1340	1340
B1	Width		920	1080	1080
H1	Height		1745	1745	1665
-	Weight	kg	665	765	815
Centre of gravity					
L2	Length	mm	600	620	650
B2	Width		400	460	460
H2	Height		830	830	860
Components					
1	S4 Turbo (F) boiler				
2	Insulation				
3	Controller				
4	Accessories package				
5	Control				

5.2 Temporary storage

If the system is to be assembled at a later stage:

- ☐ Store components at a protected location, which is dry and free from dust
 - ↳ Damp conditions and frost can damage components, particularly electric ones!

5.3 Positioning

NOTICE



Damage to components if handled incorrectly


- ☐ Follow the transport instructions on the packaging
- ☐ Transport components with care to avoid damage
- ☐ Protect the packaging against damp conditions
- ☐ Pay attention to the pallet's centre of gravity when lifting

- ☐ Position a fork-lift or similar lifting device at the pallet and bring in the components

If the boiler cannot be brought in on the pallet:

- ☐ remove the cardboard and take the boiler off the pallet
- ➔ ["Remove boiler from pallet" \[► 33\]](#)

Positioning using a crane




- ☐ Attach the crane hook to the attachment point correctly and position the boiler

5.4 Positioning at the installation site

5.4.1 Remove boiler from pallet


- ☐ Remove the cardboard with the controller from the boiler and put in a safe place
- ☐ Lift the cardboard box with the insulation from the pallet



- ☐ Remove the transport locks on both sides
- ☐ Lift boiler from pallet



TIP: use Froling's KHV 1400 boiler lifting system to help remove the pallet!



- ☐ Position a fork-lift or similar lifting device with a suitable load-bearing capacity at the base frame
- ☐ Lift it and transport it to the intended position
 - ↳ Observe the operating and maintenance areas of the equipment in the process!

TIP: To make it easier to fit the cladding, position the boiler in free space in the installation room and only move it to its final position just before connecting it hydraulically.


5.4.2 Operating and maintenance areas of the equipment

- The system should generally be set up so that it is accessible from all sides to allow quick and easy maintenance!
- Regional regulations regarding necessary maintenance areas for inspecting the chimney should be observed in addition to the specified distances!
- Observe the applicable standards and regulations when setting up the system!
- Comply with additional standards for noise protection!
(ÖNORM H 5190 - Noise protection measures)

Operating and maintenance areas of the S4 Turbo


NOTICE! The WOS lever and air control servo-motors can be installed on the left- or right-hand side! If the pellet unit is intended to be retrofitted, it is recommended to install the servomotors on the left-hand side of the boiler.

TIP: For optimum filling of the boiler with fuel we recommend that the entire door area of the insulated door should be kept clear (opening angle approx. 100°).



	S4 Turbo 22-40	S4 Turbo 50-60
A	800 mm	
B	800 mm / 200 mm ¹⁾	
C	500 mm	800 mm
D	200 mm / 800 mm ¹⁾	
E	500 mm ²⁾	
1. When using the WOS lever on the left-hand side		
2. Maintenance area to expand the WOS springs upwards		

Operating and maintenance areas of the SP Dual



1... Firewood boiler S4 Turbo F | 2... Pellet unit

	SP Dual 22-28	SP Dual 32-40
A	800 mm	
W	600 / 300 mm ¹⁾	700 / 400 mm ¹⁾
B1	1030 / 730 mm ¹⁾	1130 / 830 mm ¹⁾
C	500 mm	
D	200 / 800 mm ²⁾	
E	500 mm ³⁾	
1. When using the optional WOS drive or WOS lever on the left-hand side		
2. When using the WOS lever on the left-hand side		
3. Maintenance area to expand the WOS springs upwards		

6 Assembly

6.1 Required tools and equipment




The following tools and resources are required for assembly:

- ☐ Spanner or box wrench set (widths across flats 8 - 32 mm)
- ☐ Set of Allen keys
- ☐ Flat head and cross-head screwdrivers
- ☐ Hammer
- ☐ Diagonal cutting pliers
- ☐ Half-round file
- ☐ Power drill or cordless screwdriver with Torx bit insert
- ☐ Stepladder

6.2 Accessories supplied

The following accessories are included in the delivery and are necessary exclusively for operation of the boiler.




1	Cleaning brush 30 x 20 x 90	4	Ash drawer with bracket
2	Cleaning brush Ø 54 x 1350	5	Ash shovel
3	Furnace tool with bracket	6	Spanner for door mountings

6.3 Before Installation


6.3.1 Changing door stops (as needed)

The following steps are illustrated based on changing the fuel loading door from right-hand mounting to left-hand mounting. Perform these steps in the same way for the door of the pre-heating and combustion chamber.


RECOMMENDATION: For easier operability, we recommend that the door stop of the existing pellet unit is positioned on the left side of the boiler.



- ☐ Open the fuel loading door
- ☐ Remove the shaft retainers, pull out the hinge pins and take off the fuel loading door




- ☐ Remove the hinge and locking plate and reinstall them on the opposite side
 - ↪ Position the locking cam on the hinge as shown




- ☐ Undo the hexagon screw on the fuel loading door and remove the door handle and flange sleeve
- ☐ Turn the door handle through 180°, insert the flange bushing and attach the door handle using a hexagon head screw

For the fuel loading door



- ☐ Cautiously remove the seal, protective plate and insulating panel
- ☐ Turn the components through 180° and reinstall them on the door plate
- ☐ When doing so, use contact adhesive to fix the seal in place




- ❑ Position the fuel loading door on the hinge and secure it with the top and bottom hinge pins
- ❑ Slide the shaft retainers on to the hinge pins

NOTICE! After changing over the door stops, check the seal and adjust it as necessary.


- ➔ "Checking the seal on the doors" [▶ 39]
- ➔ "Adjusting the doors" [▶ 40]

6.3.2 Checking the seal on the doors

The following steps are illustrated based on the fuel loading door. Perform these steps in the same way for the door of the pre-heating and combustion chamber.




- ❑ Close the door
 - ↗ Slight resistance noticeable at a door gap (A) of 2-3 cm:
It is acceptable to make an adjustment at the hinge side
 - ↗ No perceptible resistance:
Move the hinge backwards
➔ "Adjusting the doors" [▶ 40]
 - ↗ If a resistance is felt when there is a gap of 3 cm:
Move the hinge plate forwards
➔ "Adjusting the doors" [▶ 40]



- ☐ Open the door
- ☐ Place a sheet of paper on both sides of the door and close the door
- ☐ Try to pull out the sheet of paper
 - ↳ If the paper cannot be pulled out:
the door is tightly sealed
 - ↳ If the paper can be pulled out:
the door is not sealed properly – move the hinge or the locking plate backwards slightly
 - ➔ ["Adjusting the doors" \[▶ 40\]](#)

6.3.3 Adjusting the doors

The following steps are illustrated based on the fuel loading door. Perform these steps in the same way for the door of the pre-heating and combustion chamber.



- ☐ Loosen the nuts on the locking plate
- ☐ Use a suitable tool, to move the locking plate forwards or backwards
- ☐ Tighten the nuts on the locking plate
- ☐ Loosen the nuts on the door hinge
- ☐ Use a hexagonal wrench (width across flats 32 mm) to move the locking cam (B) forwards or backwards
- ☐ Tighten the nuts on the hinge


IMPORTANT: Align the locking plate and hinge identically at the top and bottom

- ☐ Once the doors have been adjusted, check them again for leaks, ➔ ["Checking the seal on the doors" \[▶ 39\]](#)


6.4 Assembling the S4 Turbo 22-40

6.4.1 Assembly overview

Air duct system




Item	Quantity	Description
1	1	Induced draught fan
2	2	Pneumatic rods with air flap and springs
3	2	Air flap
4	2	Split pin

S4 Turbo 22-28 WOS system


Item	Quantity	Description
1	1	WOS lever
2	1	Plastic cover
3	4	EOS turbulator
4	1	Stay tube EOS, simple
5	2	Pipe locking pin
6	1	Heat exchanger cover

S4 Turbo 32-40 EOS system




Item	Quantity	Description
1	1	WOS lever
2	1	Plastic cover
3	1	Cover plate
4	8	EOS turbulator
5	2	Pipe locking pin
6	1	Stay tube EOS, double
7	1	Heat exchanger cover

Insulation




Item	units	Description	Item	units	Description
1	1	Insulated door	15	1	Thermal insulation of heat exchanger cover
2	1	Bottom cover plate	16	1	Securing plate (S4 Turbo 32-40)
3	1	Door mount	17	1	Controller box
4	1	Floor insulation	18	1	Controller cover
5	1	Side panel, left	19	1	Heat exchanger cover
6	2	Bracket	20	1	Cable duct cover, right-hand side
7	1	Cover plate	21	1	Side panel, right
8	1	Cable duct cover, left-hand side	22	2	Counter plate, magnetic latches
9	4	Spacer washer Ø44x4	23	2	Servo-motor cover plate
10	1	Rear thermal insulation	24	1	Torque support for actuators
11	1	Back panel	25	2	Servo-motor
12	2	Cover plate for ID fan	26	1	Door hinge
13	1	Top spacer plate	27	1	Control
14	1	Top thermal insulation			

Boiler with pellet flange



Item	Quantity	Description
1	1	Right hand side panel with the flange cut-out
2	1	LTC 2004 flow sensor for air mass measurement
3	1	Cover plate
4	1	Blanking plate, complete
5	1	Linking plate with flange cutout
6	1	S4 Turbo F boiler body with pellet flange

6.4.2 Fit the induced draught fan



- ❑ Install induced draught fan and silicone seal on the back of the boiler

↳ Straight edge (A) up


↳ Caution: do not overstress the flange!

6.4.3 Installing the pneumatic rods for the primary and secondary air

The air control servo-motors can be mounted on either the left- or right-hand side of the boiler. Delivery configuration: servo-motors on the right

NOTICE! If the servo-motors are to be assembled on the left, the air ducts must be changed on both sides!


NOTICE! Unless otherwise indicated, “right” and “left” refer to the side of the boiler when standing in front of it.




- ❑ Remove the split pin on both pneumatic rods opposite the spring and pull one of the air flaps off of each

↳ The pneumatic rods are packed along with the insulation


servo-motors on the right




- ☐ Insert both pneumatic rods into the left-hand side of the boiler
 - ↪ The air flaps with springs lie flat on the left-hand air ducts!
- ☐ Insert the air flaps on the pneumatic rods on the right-hand side and secure them with split pins
 - ↪ **IMPORTANT:** the air flaps must be in the same position as those on the opposite side!




- ☐ Turn both pneumatic rods anti-clockwise as far as the stop
 - ↪ Check the pneumatic rods can move freely

servo-motors on the left

- ☐ Remove both air ducts on the left and right-hand sides
- ☐ Fit the air ducts back onto the other side
 - ↳ The arrow on the air duct sticker should now point downwards!
 - ↳ Only partially tighten the screws!




- ☐ Insert both pneumatic rods into the right-hand side of the boiler
 - ↳ The air flaps with springs lie flat on the right-hand air ducts!
- ☐ Insert the air flaps on the pneumatic rods on the left-hand side and secure them with split pins
 - ↳ **IMPORTANT:** the air flaps must be in the same position as those on the opposite side!




- ☐ Turn both pneumatic rods anti-clockwise as far as the stop
- ↳ Check the pneumatic rods can move freely
- ☐ Tighten the screws on the air flaps

6.4.4 Installing the Lambda probe, flue gas temperature sensor and immersion sleeve




- ☐ Screw the bushing (1) into the flue gas nozzle and gently tighten
- ☐ Screw the adapter (2) into the bushing (only Lambda probe NTK OZA685 – article number 69400)
- ☐ Screw the Lambda probe (3) in and tighten slightly using an Allen key (22 mm)
- ☐ Push the flue gas temperature sensor (4) in so that it protrudes approx. 20 mm from the housing and secure the position with the wing screw (5)
- ☐ Plug in the extension cable for the Lambda probe




- ❑ Slide the boiler sensor (cable length 2 m) and the STL capillary with the contact spring (1) into the immersion sleeve of the boiler flow
- ❑ Remove the pre-installed blanking plug from the sleeve next to the immersion sleeve and then seal the supplied immersion sleeve on the thermal discharge valve
 - ↳ Thermal discharge valve not included!

6.4.5 Installing the insulation




IMPORTANT: The individual parts of the boiler insulation covered with a protective film. The protective film must be removed before proceeding with the installation!




- ❑ Place one large spacer washer (1) on each of the threaded bolts to the right and the left above on the boiler
- ❑ Insert the side panels (2) into the base of the boiler at the lug (3) and push onto the boiler
 - ↳ The holes in the side panel must line up with the holes in the flap (3)
- ❑ Position the brackets on the side panels (2) onto the threaded bolts and secure lightly with a large and a small spacer washer and nut (4)
- ❑ Secure the side panels (2) on the right and left at the flap on the boiler base with thread forming screws (5)

6.4.6 Installing the control



- ☐ Fit the control screw heads into the cutouts on the side panels
- ☐ Insert the spacer plate beneath the control
 - ↳ Ensure the spacer plate is positioned below the flap (1)
- ☐ Attach the spacer plate and control to the side panel using two screws
- ☐ Tighten both screws on the cutouts


6.4.7 Installing the back panel




- ☐ Position the rear thermal insulation on the rear side of the boiler
- ☐ Attach the back panel to the side panel
- ☐ Install the ID fan cover plate on the back panel

6.4.8 Installing the insulated door


Installation of the insulated door is explained below using the example of the door stop on the left. To mount the insulated door with the door stop on the right, invert and follow the same steps!




- ☐ Measure both diagonals and align the side panels so that the two diagonals are the same
 - ↳ Adjust the side panels if necessary
- ☐ Tighten the nuts on both brackets
- ☐ Mount the lower door bracket onto the boiler base with the half-length taper grooved pin facing outwards
 - ↳ Tighten M6 x 20 screws just slightly



- ☐ Measure the distance from the side panel to the hinge pins on the upper bracket (1)
- ☐ Measure the distance from the side panel to the half-length taper grooved pin on the lower door bracket (2)
 - ↳ The two distances must be equal!
 - ↳ If necessary, correct the position of the lower door bracket and tighten in place
- ☐ Place the spacer washer on the half-length taper grooved pin




- ❑ Mount counter plates for magnetic latches on the side panel on the opposite side of the door stop
- ❑ Hang the insulated door at the bottom onto the half-length taper grooved pin and secure at the top with a door pin



- ❑ Check to see if the gap between the side panel and the insulated door is the same along the entire height of the boiler
 - ↪ If necessary, adjust the position of the lower door bracket (1)


6.4.9 Attaching the controller

S4 Turbo 22-28:




- ☐ Place the thermal insulation on the boiler
 - ⚠ Take care not to damage the cable of the door contact switch (A)
- ☐ Thread the controller box on the lugs and push the box to the back
- ☐ Use four screws incl. contact washers and mount controller box

S4 Turbo 32-40:





- ☐ Place the thermal insulation on the boiler
 - ⚠ Take care not to damage the cable of the door contact switch (A)
- ☐ Thread the securing plate on the lugs and push the box to the back
- ☐ Use two screws and contact washers to attach the securing plate



- ☐ Use four screws incl. contact washers and mount controller box onto the securing plate

6.4.10 Installing the servo-motors

NOTICE! The images show a boiler with the servo-motors installed in the right




At the servo-motor end:


- ☐ Undo both the bottom screws on the bottom air duct and fit the bracket
- ☐ Fit cover plates over the side panel and bracket

At the other end:

- ☐ Undo both the bottom screws on the bottom air duct and fit the bracket
- ☐ Fit a cover plate over the side panel and bracket



- ☐ Set the direction of rotation of the servo-motor (1) to anticlockwise (L)
- ☐ Press the unlock fitted key (2) and turn the drive for the shaft to the air duct (3) in the anti-clockwise direction as far as the stop
- ☐ Turn the square shafts of the air flaps anti-clockwise to the stop
- ☐ Attach the servo-motors to the square shafts and secure them together with the torque supports
- ☐ Push in the pre-punched opening in the insulation to admit the cable duct
- ☐ Apply a sticker to the servo-motor cable, close to the plug
 - ↳ Primary air = upper servo-motor / secondary air = lower servo-motor
- ☐ Run the cables for the two servo-motors through the cable duct upwards to the boiler controller




6.4.11 Installing the WOS lever


The WOS lever can be mounted on either the left or the right side on the boiler.

NOTICE! The WOS lever must be installed on the right-hand side of the boiler in order to retrofit the pellet unit at a later date.

S4 Turbo 22-28




- ☐ Loosen the lock nut on the star-shaped knob of the heat exchanger cover
- ☐ Turn the star-shaped knob counterclockwise and remove the heat exchanger cover
- ☐ Remove the pre-punched blanking (1) to the side panel
 - ↳ File rough edges using a half-round file and remove burrs
- ☐ Slide the plastic cover onto the WOS lever
- ☐ Push the WOS lever through the stay tube from the outside




- ☐ Use two pipe locking pins in order to secure the WOS lever to the stay tube
- ☐ Place the heat exchanger cover on top
- ☐ Turn the star-shaped knob on the heat exchanger cover clockwise and use the lock nut to secure the cover

S4 Turbo 32-40



- ☐ Loosen the lock nuts on the star-shaped knobs of the heat exchanger cover
- ☐ Turn the star-shaped knobs counterclockwise and remove the heat exchanger cover
- ☐ Remove the front pre-punched blanking from the side panel
 - ↳ File rough edges using a half-round file and remove burrs
- ☐ Installing the cover plate
- ☐ Slide the plastic cover onto the WOS lever
- ☐ Push the WOS lever through the stay tube from the outside




- ☐ Use two pipe locking pins in order to secure the WOS lever to the stay tube
- ☐ Place the heat exchanger cover on top
- ☐ Turn the star-shaped knobs on the heat exchanger cover clockwise and use the lock nut to secure the cover

6.5 Assembling the S4 Turbo 50-60


6.5.1 Assembly overview

Air duct system




Item	Quantity	Description
1	1	Induced draught fan
2	1	Induced draught unit housing
3	1	Mineral fibre seal
4	2	Pneumatic rods with air flap and springs
5	2	Air flap
6	2	Split pin

EOS system



Item	Quantity	Description
1	1	WOS lever
2	1	Plastic cover
3	1	Cover plate
4	14	EOS turbulator
5	1	Stay tube EOS, double
6	1	Stay tube EOS, simple
7	2	Pipe locking pin
8	1	Heat exchanger cover
9	1	Shaft

Insulation




Item	units	Description	Item	units	Description
1	1	Control	18	1	Induced draft cover
2	1	Door hinge	19	1	Strain relief
3	1	Insulated door	20	2	Cover plate for ID fan
4	1	Door mount	21	1	Thermal insulation of heat exchanger cover
5	1	Bottom cover plate	22	1	Top thermal insulation
6	1	Floor insulation	23	1	Top spacer plate
7	4	Spacer washer Ø44x4	24	1	Securing plate
8	1	Cable duct cover, left-hand side	25	1	Controller box
9	1	Side panel, left	26	1	Controller cover
10	2	Bracket	27	1	Heat exchanger cover
11	1	Cover plate	28	1	Cable duct cover, right-hand side
12	1	Rear thermal insulation	29	1	Side panel, right
13	1	Back panel	30	2	Counter plate for magnetic latches
14	4	Cable guide	31	2	Servo-motor cover plate
15	1	Thermal insulation, ID fan	32	1	Torque support
16	1	Cladding, ID fan	33	2	Servo-motor
17	1	Cable duct			

6.5.2 Installing the pneumatic rods for the primary and secondary air


The air control servo-motors can be mounted on either the left- or right-hand side of the boiler. Delivery configuration: servo-motors on the right

NOTICE! If the servo-motors are to be assembled on the left, the air ducts must be changed on both sides!


NOTICE! Unless otherwise indicated, “right” and “left” refer to the side of the boiler when standing in front of it.



- ☐ Remove the split pin on both pneumatic rods opposite the spring and pull one of the air flaps off of each
 - ↳ The pneumatic rods are packed along with the insulation


servo-motors on the right

- ☐ Insert both pneumatic rods into the left-hand side of the boiler
 - ↳ The air flaps with springs lie flat on the left-hand air ducts!
- ☐ Insert the air flaps on the pneumatic rods on the right-hand side and secure them with split pins
 - ↳ **IMPORTANT:** the air flaps must be in the same position as those on the opposite side!




- ☐ Turn both pneumatic rods anti-clockwise as far as the stop
 - ↳ Check the pneumatic rods can move freely


servo-motors on the left



- ☐ Remove both air ducts on the left and right-hand sides
- ☐ Fit the air ducts back onto the other side
 - ↳ The arrow on the air duct sticker should now point downwards!
 - ↳ Only partially tighten the screws!




- ☐ Insert both pneumatic rods into the right-hand side of the boiler
 - ↳ The air flaps with springs lie flat on the right-hand air ducts!
- ☐ Insert the air flaps on the pneumatic rods on the left-hand side and secure them with split pins
 - ↳ **IMPORTANT:** the air flaps must be in the same position as those on the opposite side!




- ☐ Turn both pneumatic rods anti-clockwise as far as the stop
 - ↳ Check the pneumatic rods can move freely
- ☐ Tighten the screws on the air flaps

6.5.3 Installing the insulation




IMPORTANT: The individual parts of the boiler insulation covered with a protective film. The protective film must be removed before proceeding with the installation!




- ☐ Place one large spacer washer (1) on each of the threaded bolts to the right and the left above on the boiler
- ☐ Insert the side panels (2) into the base of the boiler at the lug (3) and push onto the boiler
 - ↳ The holes in the side panel must line up with the holes in the flap (3)
- ☐ Position the brackets on the side panels (2) onto the threaded bolts and secure lightly with a large and a small spacer washer and nut (4)
- ☐ Secure the side panels (2) on the right and left at the flap on the boiler base with thread-forming screws (5)

6.5.4 Installing the control



- ☐ Fit the control screw heads into the cutouts on the side panels
- ☐ Insert the spacer plate beneath the control
 - ↳ Ensure the spacer plate is positioned below the flap (1)
- ☐ Attach the spacer plate and control to the side panel using two screws
- ☐ Tighten both screws on the cutouts


6.5.5 Installing the back panel




- ☐ Position the rear thermal insulation on the rear side of the boiler
- ☐ Attach the back panel to the side panel

6.5.6 Installing the insulated door


Installation of the insulated door is explained below using the example of the door stop on the left. To mount the insulated door with the door stop on the right, invert and follow the same steps!




- ☐ Measure both diagonals and align the side panels so that the two diagonals are the same
 - ↳ Adjust the side panels if necessary
- ☐ Tighten the nuts on both brackets
- ☐ Mount the lower door bracket onto the boiler base with the half-length taper grooved pin facing outwards
 - ↳ Tighten M6 x 20 screws just slightly



- ☐ Measure the distance from the side panel to the hinge pins on the upper bracket (1)
- ☐ Measure the distance from the side panel to the half-length taper grooved pin on the lower door bracket (2)
 - ↳ The two distances must be equal!
 - ↳ If necessary, correct the position of the lower door bracket and tighten in place
- ☐ Place the spacer washer on the half-length taper grooved pin




- ❑ Mount counter plates for magnetic latches on the side panel on the opposite side of the door stop
- ❑ Hang the insulated door at the bottom onto the half-length taper grooved pin and secure at the top with a door pin




- ❑ Check to see if the gap between the side panel and the insulated door is the same along the entire height of the boiler
 - ↪ If necessary, adjust the position of the lower door bracket (1)

6.5.7 Attaching the controller




- ❑ Place the thermal insulation on the boiler
 - ↪ Take care not to damage the cable of the door contact switch (A)
- ❑ Thread the securing plate on the lugs and push the box to the back
- ❑ Use two screws and contact washers to attach the securing plate




- ☐ Use four screws incl. contact washers and mount controller box onto the securing plate


6.5.8 Install the Lambda probe, sensor and thermal discharge valve



- ☐ Screw the bushing (1) into the flue gas nozzle and gently tighten
- ☐ Screw adapter (2) into bushing (only for Lambda probe NTK OZA685 – Item no. 69400)
- ☐ Screw in the Lambda probe (3) and tighten slightly using an Allen key (22 mm)
- ☐ Push the flue gas temperature sensor (4) in so that it protrudes approx. 20 mm from the housing and secure the position with the wing screw (5)
- ☐ Plug in the extension cable for the Lambda probe





- ☐ Push the boiler sensor and the STL capillary with the pressure spring (1) into the immersion sleeve of the boiler flow.
- ☐ Remove the pre-installed blanking plug from the sleeve next to the immersion sleeve and seal the supplied immersion sleeve for the thermal discharge valve
- ↳ Thermal discharge valve not included!



- ☐ Slide the sensor and metal tube insulation into the immersion sleeve and secure with slotted screw
- ☐ Run the cable from the Lambda probe, flue gas temperature and boiler sensors and STL capillary to the controller box via the cable duct
- ↳ Tuck any extra cable into the cable duct
- ☐ Install cover plates on the left and right cable ducts

6.5.9 Installing the servo-motors

NOTICE! The images show a boiler with the servo-motors installed in the right




At the servo-motor end:


- ☐ Undo both the bottom screws on the bottom air duct and fit the bracket
- ☐ Fit cover plates over the side panel and bracket

At the other end:


- ☐ Undo both the bottom screws on the bottom air duct and fit the bracket
- ☐ Fit a cover plate over the side panel and bracket




- ☐ Set the direction of rotation of the servo-motor (1) to anticlockwise (L)
- ☐ Press the unlock fitted key (2) and turn the drive for the shaft to the air duct (3) in the anti-clockwise direction as far as the stop
- ☐ Turn the square shafts of the air flaps anti-clockwise to the stop
- ☐ Attach the servo-motors to the square shafts and secure them together with the torque supports
- ☐ Push in the pre-punched opening in the insulation to admit the cable duct
- ☐ Apply a sticker to the servo-motor cable, close to the plug
 - ↳ Primary air = upper servo-motor / secondary air = lower servo-motor
- ☐ Run the cables for the two servo-motors through the cable duct upwards to the boiler controller




6.5.10 Installing the induced draught fan




- Install induced draught unit housing and mineral fibre seal on the flue gas nozzle
- Install induced draught fan on the induced draught fan unit housing
 - ↳ Straight edge (A) top
 - ↳ Caution: do not overstress the flange!



- Push the four cable guides into the holes on the back panel above the flue gas nozzle
 - ↳ Run the cable from the Lambda probe and flue gas temperature sensor through the cable guides
 - ↳ IMPORTANT: The cables must not come into contact with the flue pipe.
- Wrap the thermal insulation around the ID fan housing




- Fix the thermal insulation in place using tension springs
- Attach the cladding on the top of the ID fan housing using pre-installed screws
- Install the ID cover plates on the back of the cladding




- ☐ Plug in the connection cable of the induced draught fan (power supply and speed measurement)
- ☐ Mount the cable duct in the slots on the side of the cladding
- ☐ Attach the cable duct to position the cable and run it to the boiler controller
- ☐ Clamp the cable from the Lambda probe and flue gas temperature sensor into the strain relief
- ☐ Insert the strain relief into the cut-out of the cover plate and fix it in place by rotating it 90°
- ☐ Attach the cover plate on the top of the ID fan housing using pre-installed screws
- ☐ Run the cable to the boiler controller

6.5.11 Installing the WOS lever

The heat-exchanger lever can be mounted on either the left or the right side on the boiler.



- ☐ Loosen the lock nuts on the star knobs of the heat exchanger cover
- ☐ Turn the star knobs anti-clockwise and remove the heat exchanger cover
- ☐ Remove the front pre-punched blanking in the side panel
 - ↳ File rough edges using a half-round file and remove burrs
- ☐ Install cover plate
- ☐ Slide the plastic cover onto the EOS lever
- ☐ Push the WOS lever through the stay tube from the outside



- ☐ Attach the WOS lever to the stay tube using two pipe locking pins
- ☐ Place the heat exchanger cover on top
- ☐ Turn the star knobs on the heat exchanger cover clockwise and use a lock nut to secure against rotation

6.6 Electrical connection and wiring

DANGER




When working on electrical components:

Risk of electrocution!

When work is carried out on electrical components:


- ☐ Always have work carried out by a qualified electrician
- ☐ Observe the applicable standards and regulations
 - ↳ Work must not be carried out on electrical components by unauthorised persons

Prepare the plug some components come ready to connect with the cable fixed to the tag connector with cable tie.



- ☐ Remove the cable ties from the tag connector
- ☐ Bind the individual cores together with cable ties (A)
- ☐ Attach cable and cable ties to the strain reliefs on the boiler

6.6.1 Board overview












Item	Description	Item	Description
1	High-limit thermostat STL	6	Ignition expansion (optional)
2	Service interface	7	Hydraulic module
3	Main switch	8	Core module
4	Device connection terminal	9	Mains connection plug
5	Return mixer module (optional)		


6.6.2 Connect the firewood boiler components

- Run the cables of the following components to the boiler controller and connect them to the boards in the controller box
- ↳ Tuck any extra cable into the cable duct


Core module:



KM-02		Boiler display	KM-13		Lambda probe
KM-06		Broadband probe (alternative to the Lambda probe)	KM-15		Flue gas temperature sensor
KM-07		Secondary air servo-motor	KM-16		Door switch
KM-08		Primary air servo-motor	KM-25		Boiler sensor

KM-10



High-limit thermostat

KM-27


Induced draught fan


Once the individual components have been wired:

Mains connection:




- ❑ Create a mains connection for the mains plug in the boiler controller
 - ↪ The power supply line (network connection) must be fitted with a max. C16A fuse by the customer!
 - ↪ Observe the circuit diagrams in the boiler controller operating instructions.
 - ↪ Flexible sheathed cable must be used for the wiring; this must be of the correct size to comply with applicable regional standards and regulations

6.6.3 Potential equalisation




- ❑ Create potential equalisation of the boiler base as specified by current regulations and standards.


6.7 Concluding work



- ☐ Slide the sensor and metal tube insulation of the thermal discharge safety valve into the immersion sleeve and secure with slotted screw
- ☐ Attach the left and right cover plates to the cable ducts




- ☐ Thread the controller cover on to the control and secure it with screws incl. contact washers
- ☐ Put on the thermal insulation and rear insulating cover



- ☐ Push in the floor insulation
- ☐ Insert the cover plate under the combustion chamber door
- ☐ Hook the left-hand and right-hand angled lugs into the recess (1) on the boiler base


6.7.1 Positioning the boiler stickers



- ☐ Remove the protective film from the sticker
- ☐ Position the backing film featuring “S4 TURBO” in the upper left corner of the insulating door, ensuring all of the air bubbles have been removed
- ☐ Make several passes over the sticker so the writing adheres to the insulating door
- ☐ Carefully pull off the backing film


6.7.2 Insulate the connection line

When using the optionally available thermal insulation supplied by Fröling GesmbH, perform the following steps:




- ☐ Cut the half shells of thermal insulation to length and lay them on the connection line
- ☐ Create an opening for access to the measuring port
- ☐ Apply protective foil at the projecting lugs
- ☐ Glue the half shells to each other

6.7.3 Install the brackets for accessories



- ☐ Using appropriate fasteners, attach the brackets to the wall on the boiler
- ☐ Attach the accessories to the brackets

6.8 Hydraulic connection



1 Thermal discharge valve

- The thermal discharge safety device must be connected in accordance with ÖNORM/ DIN EN 303-5 and as shown in the diagram above
- The discharge safety sensor must be connected to a pressurised cold water mains supply (temperature $\leq 15^{\circ}\text{C}$) in such a way that it cannot be shut off
- A pressure reducing valve (1.5) is required for a cold water pressure of ≥ 6 bar
Minimum cold water pressure = 2 bar

1.1 Sensor of thermal discharge safety device

1.2 Thermal discharge valve (opens at approx. 95°C)

1.3 Cleaning valve (T-piece)

1.4 Dirt trap

1.5 Pressure reducing valve

1.6 Backflow preventer to prevent stagnation water from entering the drinking water network

1.7 Free outlet without counter pressure with observable flow path (e.g. discharge funnel)

2 Safety valve

- Requirements for safety valves as specified by DIN EN ISO 4126-1
- Minimum diameter for the inlet to the safety valve as specified by EN 12828:
DN15 (≤ 50 kW), DN20 (> 50 to ≤ 100 kW), DN25 (> 100 to ≤ 200 kW), DN32 (> 200 to ≤ 300 kW), DN40 (> 300 to ≤ 600 kW), DN50 (> 600 to ≤ 900 kW)
- Maximum pressure setting in terms of the permissible operating pressure of the boiler, see the section "Technical Data"
- The safety valve must be installed in an accessible place on the boiler or in direct proximity in the flow pipe in such a way that it cannot be shut off
- Unhindered and safe escape of the steam or water that is released must be ensured

3 Return temperature control

4 Diaphragm expansion tank

- The diaphragm pressurised expansion tank must conform to EN 13831 and hold at least the maximum expansion volume of the heated water in the system, including a water seal
- Its size must comply with the design information in EN 12828 - Appendix D
- Ideally it should be installed in the return line. Follow the manufacturer's installation instructions

5 We recommend installing some sort of monitoring device (such as a thermometer)

7 Start-up

7.1 Before commissioning / configuring the boiler

The boiler must be configured to the heating system during initial start-up!

NOTICE

Optimum efficiency and efficient, low-emission operation can only be guaranteed if the system is set up by trained professionals and the standard factory settings are observed.

Take the following precautions:

- ☐ Initial startup should be carried out with an authorised installer or with Froling customer services

NOTICE

Foreign bodies in the heating system impair its operational safety and can result in damage to property.

As a result:

- ☐ The whole system should be rinsed out before initial start-up in accordance with EN 14336.
- ☐ Recommendation: Make sure the hose diameter of the flush nozzles in the flow and return complies with ÖNORM H 5195 and is the same as the hose diameter in the heating system, however not more than DN 50.

- ☐ Turn on the main switch
- ☐ Set the boiler controller to the system type.
- ☐ Load the boiler default values.

NOTICE! For the keypad layout and instructions for modifying the parameters, see the instruction manual for the boiler controller.

- ☐ Check the system pressure of the heating system.
- ☐ Check that the heating system is fully ventilated
- ☐ Check all quick vent valves of the entire heating system for leaks
- ☐ Check that all water connections are tightly sealed
 - ↳ Pay particular attention to those connections from which plugs were removed during assembly.
- ☐ Check that all necessary safety devices are in place
- ☐ Check that there is sufficient ventilation in the boiler room.
- ☐ Check the seal of the boiler.
 - ↳ All doors and inspection openings must be tightly sealed.
- ☐ Check all blanking plugs (e.g. drainage) for tightness
- ☐ Check that the drives and servo motors are working and turning in the right direction
- ☐ Check that the door contact switch is working efficiently.

NOTICE! Check the digital and analogue inputs and outputs - See the instruction manual for the boiler controller.

7.2 Initial startup

7.2.1 Permitted fuels

Firewood

Firewood up to max. 55 cm long.

Water content

Water content (w) greater than 15% (equivalent to wood moisture $u > 17\%$)

Water content (w) less than 25% (equivalent to wood moisture $u < 33\%$)

Note on standards

EU: Fuel as per EN ISO 17225 – Part 5: Firewood class A2 / D15 L50

Additional for Germany: Fuel class 4 (§3 of the First Federal Emissions Protection Ordinance (BimSchV) in the last amended version)

Tips for storing wood

- Use wind-exposed areas where possible for storage (e.g. store at edge of forest instead of in forest)
- Walls of buildings facing the sun are ideal
- Create a dry underlay, where possible with air access (line with round timber, pallets, etc.)
- stack split wood and store in such a way that it is protected from the elements
- If possible, stock fuel for the day in a warm place (e.g. in boiler room) (pre-heats the fuel!)

Storage time dependent upon water content

	Wood type	Water content	
		15 – 25%	less than 15 %
Storage in heated and ventilated room (approx. 20°C)	Soft wood (e.g. spruce)	approx. 6 months	from 1 year
	Hardwood (e.g. beech)	1 – 1.5 years	from 2 years
Outdoor storage (protected from elements, exposed to wind)	Soft wood (e.g. spruce)	2 summers	from 2 years
	Hardwood (e.g. beech)	3 summers	from 3 years

Freshly cut wood has an approximate water content of 50 to 60% depending on when it was harvested. As the above table shows, the water content of the firewood decreases the longer the wood is stored depending on how dry and warm the storage location is. The ideal water content of firewood is between 15 and 25%. If the water content falls below 15%, we recommend you adjust the combustion control to the fuel.

The air duct should be adjusted accordingly for optimal burning of these fuels ($w < 15\%$).
Extra cleaning of flue gas paths

7.2.2 Fuels permitted under certain conditions

Wood briquettes

Wood briquettes for non-industrial use with a diameter of 5-10 cm and 5-50 cm long.

Note on standards

EU:	Fuel as per EN ISO 17225 - Part 3: wood briquettes class B / D100 L500 Form 1 - 3
Additional for Germany:	Fuel class 5a (§3 of the First Federal Emissions Protection Ordinance (BImSchV) - applicable version)

Notes on use

- When burning wood briquettes use the settings for extremely dry fuel
- Wood briquettes must be heated up with firewood as per EN ISO 17225-5 (at least two layers of firewood under the wood briquettes)
- The fuel loading chamber must not be filled more than 3/4 full, as the wood briquettes expand during combustion
- Even when using the settings for dry fuel, burning wood briquettes can cause combustion problems. In such cases, repairs must be carried out by qualified staff. Please contact Froling customer services or your installer.

7.2.3 Non-permitted fuels

The use of fuels other than those defined in the "Permitted fuels" section, and particularly the burning of refuse, is not permitted

NOTICE

In case of use of non-permitted fuels:

Burning non-permitted fuels increases the cleaning requirements and leads to a build-up of aggressive sedimentation and condensation, which can damage the boiler and also invalidates the guarantee! Using non-standard fuels can also lead to serious problems with combustion!

For this reason, when operating the boiler:

- ☐ Use only the permitted fuels

7.2.4 Heating up for the first time

CAUTION


If the boiler heats up too quickly on initial start-up:

If the output during the heating-up process is too great, the combustion chamber may be damaged as a result of drying out too rapidly!

For this reason the following applies the first time you heat up the boiler:

- ☐ Start the firewood boiler for the first time in accordance with the heating instructions

Heating instructions when starting up a firewood boiler for the first time



- ❑ Place a piece of wood diagonally across the combustion chamber (see diagram on left)
- Load the boiler with a small amount of firewood (max. 10-20% of the fuel loading chamber)
- Ignite it and allow it to burn slowly with the central pre-heating chamber door open

NOTICE! Fissures are normal and do not indicate a malfunction

Once the material in the boiler has burnt down, the boiler can be used in accordance with the operating instructions ("Operating the system" section).

NOTICE

If condensation escapes during the initial heat-up phase, this does not indicate a fault.

- ❑ Tip: If this occurs, clean up using a cleaning rag.

NOTICE! See boiler controller instruction manual for all the steps necessary to start up for the first time.

8 Decommissioning

8.1 Mothballing

The following measures should be taken if the boiler is to remain out of service for several weeks (e.g. during the summer):

- ☐ Clean the boiler thoroughly and close the doors fully

If the boiler is to remain out of service during the winter:

- ☐ Have the system completely drained by a qualified technician
 - ↳ Protection against frost

8.2 Disassembly

To disassemble the system, follow the steps for assembly in reverse order.

8.3 Disposal

- ☐ Ensure that they are disposed of in an environmentally friendly way in accordance with waste management regulations in the country (e.g. AWG in Austria)
- ☐ You can separate and clean recyclable materials and send them to a recycling centre.
- ☐ The combustion chamber must be disposed of as builders' waste.

9 Appendix

9.1 Pressure equipment regulation

ZERTIFIKAT ◆ CERTIFICATE ◆ ЗЕРТИФІКАТ ◆ CERTIFICADO ◆ CERTIFICAT ◆ 01 Dpr-252 Zertifikat B 16.06.2023 Rev.0			
	EU-Baumusterprüfbescheinigung <i>Certificate</i>		
	EU-Baumusterprüfung (Modul B 3.2 Entwurfsmuster) nach Richtlinie 2014/68/EU <i>EU-Type-examination (Module B 3.2 design type) according to directive 2014/68/EU</i>		
	Zertifikat-Nr.: <i>Certificate-No.:</i>	0531-PED-VE-3135	
	Zeichen des Auftraggebers: <i>Reference of Applicant:</i>	Auftragsdatum: <i>Date of Application:</i>	Inspektionsbericht-Nr.: <i>Inspection report Nr.:</i>
	4000302077	11.07.2023	VE 725226353-1-JKo
	Hersteller: <i>Manufacturer:</i>	Fa. Fröling Heizkessel-u. Behälterbau Ges.m.b.H.	
	In/ of	Industriestraße 12 A- 4710 Grieskirchen	
	Hiermit wird bestätigt, dass das hier genannte EG-Baumuster die Anforderungen der Richtlinie 2014/68/EU erfüllt.		
	<i>We herewith certify that the type mentioned meets the requirements of the Directive 2014/68/EU.</i>		
Geprüft nach: <i>Tested in accordance with:</i>	Richtlinie 2014/68/EU, Artikel 4(2)		
Beschreibung des Produktes: <i>Description of product:</i>	Scheitholzkessel S4 Turbo 22 + 22F, 28 + 28F, 32 + 32F, 34 + 34F, 40 + 40F, 50 + 50F, 60 + 60F		
	Bedienungsanleitung B1510622_de I Ausgabe 27.09.2022, Montageanleitung M0971821_de I Ausgabe 16.06.2021		
Gültig bis: <i>Valid to:</i>	24.08.2033		
	TÜV SÜD Landesgesellschaft Österreich GmbH		
Wien/ Vienna, 17.10.2023			
	Notifizierte Stelle, Kennnummer 0531 <i>Notified Body, identification number 0531</i> (Dipl.-Ing. (FH) Josef Kogler)		
Bitte beachten Sie die Hinweise auf der zweiten Seite. <i>Please note the remarks on the second page.</i>	Tel.: +43 (0)5 0528 - 4400 Fax: +43 (0)5 0528 - 1077		
TÜV SÜD Landesgesellschaft Österreich GmbH, Franz-Grill-Straße 1, Arsenal, Objekt 207, 1030 Wien - Austria			
			

Notes

[illegible]

[illegible]

Manufacturer's address

Fröling Heizkessel- und Behälterbau GesmbH

Industriestraße 12
A-4710 Grieskirchen
+43 (0) 7248 606 0
info@froeling.com

Zweigniederlassung Aschheim

Max-Planck-Straße 6
85609 Aschheim
+49 (0) 89 927 926 0
info@froeling.com

Froling srl

Via J. Ressel 2H
I-39100 Bolzano (BZ)
+39 (0) 471 060460
info@froeling.it

Froling SARL

1, rue Kellermann
F-67450 Mundolsheim
+33 (0) 388 193 269
froling@froeling.com

Installer's address

Stamp

Froling customer services

Austria
Germany
Worldwide

0043 (0) 7248 606 7000
0049 (0) 89 927 926 400
0043 (0) 7248 606 0



www.froeling.com

froling 